



Source 1
REPLACEMENT PARTS

DW-15/-18/-20/-25

Supersedes: Nothing

035-18947-000 Rev. A (0702)

Note: This is a non-comprehensive parts lists intended for stocking purposes for first production (style A) units. It is not intended to replace the complete, comprehensive list with subsequent changes.

Part Number	Description	Notes or code on wiring diagram	Model and Voltage												
			DW-15			DW-18			DW-20			DW-25			
			230V	460V	575V	230V	460V	575V	230V	460V	575V	230V	460V	575V	
025-38231-000	ACTUATOR,ECON HONEYWELL M7215		X	X	X	X	X	X	X	X	X	X	X	X	X
029-20424-000	BEARING,BALL,PILLOW BLOCK		X	X	X										
029-22144-000	BEARING,BALL,4 BOLT FLG												X	X	X
029-22145-000	BEARING,BALL,4 BOLT FLG					X	X	X	X	X	X				
026-35494-000	BRACKET,BEARING														
029-18431-000	BURNER,GAS		X	X	X	X	X	X	X	X	X	X	X	X	X
028-13332-000	BUSHING,B1, 1.438BORE					X	X	X					X	X	X
024-20043-000	CAPACITOR,RUN, 5.0/ MFD,370V	RC1, RC2, RC3, RC4	X	X	X	X	X	X							
024-21219-000	CAPACITOR,RUN,12.5/ MFD,370V	RC1, RC2, RC3, RC4							X	X	X	X	X	X	X
029-15650-000	CATCH,MAGNETIC		X	X	X	X	X	X	X	X	X	X	X	X	X
024-27583-000	CIRCUIT BREAKER *	CB2	X	X	X	X	X	X	X	X	X	X	X	X	X
024-31976-000	CIRCUIT BREAKER *	CB1 & CB3	X	X	X	X	X	X	X	X	X	X	X	X	X
024-27517-000	CIRCUIT BREAKER, 20 AMP *	CB4													
024-27648-000	CIRCUIT BREAKER, 30 AMP,600V *	DS1													
024-26010-000	CIRCUIT BREAKER, 35A 480V *	DS1													
024-31963-000	CIRCUIT BREAKER, 40A 480V *	DS1													
024-27652-000	CIRCUIT BREAKER, 40A 600V *	DS1													
024-27643-000	CIRCUIT BREAKER, 45A 480V *	DS1													
024-27573-000	CIRCUIT BREAKER, 45A 600V *	DS1													
024-26063-000	CIRCUIT BREAKER, 50A 480V *	DS1													
024-27647-000	CIRCUIT BREAKER, 50A 600V *	DS1													
024-27572-000	CIRCUIT BREAKER, 60A 600V *	DS1													
024-27508-000	CIRCUIT BREAKER, 70A 480V *	DS1													
024-27571-000	CIRCUIT BREAKER, 70A 600V *	DS1													
024-27503-000	CIRCUIT BREAKER, 80A 240V *	DS1													
024-26070-000	CIRCUIT BREAKER, 90A 240V *	DS1													
024-27507-000	CIRCUIT BREAKER, 90A 480V *	DS1													
024-27570-000	CIRCUIT BREAKER, 90A 600V *	DS1													
024-32035-000	CIRCUIT BREAKER, 100A 3P *	DS1													
024-27675-000	CIRCUIT BREAKER, 100A 480V *	DS1													
024-31959-000	CIRCUIT BREAKER, 110A 240V *	DS1													
024-27514-000	CIRCUIT BREAKER, 110A 600V *	DS1													
024-31960-000	CIRCUIT BREAKER, 125A 240V *	DS1													
024-27513-000	CIRCUIT BREAKER, 125A 600V *	DS1													
024-27548-000	CIRCUIT BREAKER, 150A 600V *	DS1													
024-31962-000	CIRCUIT BREAKER, 175A 240V *	DS1													
024-32040-000	CIRCUIT BREAKER, 200A 240V *	DS1													
024-27509-000	CIRCUIT BREAKER, 225A 600V *	DS1													
024-32037-000	CIRCUIT BREAKER, 600V 80A *	DS1													
026-38369-000	CLAMP,MOTOR,WIREFORM		X	X	X	X	X	X	X	X	X	X	X	X	X
373-25783-001	COIL,COND LEFT					X	X	X	X	X	X	X	X	X	X
373-25789-001	COIL,COND LEFT		X	X	X										
373-25783-002	COIL,COND RIGHT					X	X	X	X	X	X	X	X	X	X
373-25789-002	COIL,COND RIGHT		X	X	X										
373-21474-001	COIL,EVAP LOWER					X	X	X	X	X	X	X	X	X	X
373-25791-001	COIL,EVAP LOWER		X	X	X										
373-21473-001	COIL,EVAP UPPER					X	X	X	X	X	X	X	X	X	X
373-25790-001	COIL,EVAP UPPER		X	X	X										
015-03518-004	COMPRESSOR,H20R813DBEA	COMPR		X											
015-03519-004	COMPRESSOR,H20R813DBFA	COMPR			X										
015-03517-004	COMPRESSOR,H20R813DBLA	COMPR	X												
015-03416-004	COMPRESSOR,H20R943DBEA	COMPR				X									
015-03417-004	COMPRESSOR,H20R943DBFA	COMPR					X								
015-03412-004	COMPRESSOR,H20R943DBLA	COMPR				X									
015-03510-004	COMPRESSOR,ZR108KC-TF5	COMPR						X							
015-03511-004	COMPRESSOR,ZR108KC-TFD	COMPR							X						
015-03512-004	COMPRESSOR,ZR108KC-TFE	COMPR								X					
015-03529-004	COMPRESSOR,ZR144KC-TF5	COMPR									X				
015-03248-004	COMPRESSOR,ZR144KC-TFD	COMPR										X			
015-03528-004	COMPRESSOR,ZR144KC-TFE	COMPR											X		
024-27531-000	CONTACTOR	M4, M5	X	X	X	X	X	X	X	X	X	X	X	X	X
024-25955-000	CONTACTOR,ELEC,30 AMP	M1, M2	X	X	X	X	X	X	X	X	X	X	X	X	X
024-25955-000	CONTACTOR,ELEC,30 AMP	M3	X	X	X	X	X	X	X	X	X	X	X	X	X
024-25844-000	CONTACTOR,ELEC,40 AMP	M1, M2							X						
024-25844-000	CONTACTOR,ELEC,40 AMP	M3										X			
024-25846-000	CONTACTOR,ELEC,50 AMP	M1, M2								X					

* See UNIT NAMEPLATE or TECHNICAL LITERATURE for the required breaker/max fuse size.

New replacement parts shown in **bold face** at the printing of the Parts List code dated (0702).

Part Number	Description	Notes or code on wiring diagram	Model and Voltage												
			DW-15			DW-18			DW-20			DW-25			
			230V	460V	575V	230V	460V	575V	230V	460V	575V	230V	460V	575V	
031-01965-000	CONTROL,ECONO, HONEYWELL		X	X	X	X	X	X	X	X	X	X	X	X	X
031-00863-000	CONTROL,ENTHALPY	RELATIVE HUMIDITY SENSOR	X	X	X	X	X	X	X	X	X	X	X	X	X
031-01934-002	CONTROL,SIMPLICITY LOCKOUT	CONTROL BOARD UCB	X	X	X	X	X	X	X	X	X	X	X	X	X
025-26366-009	CONTROL,TEMP	LS	X	X	X	X	X	X	X	X	X	X	X	X	X
025-27723-001	CONTROL,TEMP	LAS1 & LAS2	X	X	X	X	X	X	X	X	X	X	X	X	X
025-27727-002	CONTROL,TEMP	FS1 & FS2	X	X	X	X	X	X	X	X	X	X	X	X	X
025-32655-000	CONTROL,TEMP	AUX LIMIT	X	X	X	X	X	X	X	X	X	X	X	X	X
025-27733-002	CONTROL,TEMP (ROLLOUT SWITCH)	RS	X	X	X	X	X	X	X	X	X	X	X	X	X
025-35355-001	CONTROL,TEMP SPST 30F	LAS3	X	X	X	X	X	X	X	X	X	X	X	X	X
025-32675-000	COVER, DISC SWITCH/CONV OUTLET		X	X	X	X	X	X	X	X	X	X	X	X	X
029-22116-000	CRANKARM, ECONOMIZER		X	X	X	X	X	X	X	X	X	X	X	X	X
029-22198-000	DETECTOR, SMOKE	RET AIR & NO ECON	X	X	X	X	X	X	X	X	X	X	X	X	X
026-35506-000	DISTR,14T,#10,.187X30S EVAP COIL	ID COIL	X	X	X	X	X	X	X	X	X	X	X	X	X
026-34758-000	FAN,PROP,24DIA,3BL,27DEG	OD FAN	X	X	X	X	X								
026-35579-000	FAN,PROP,30DIA,3BL,18DEG	OD FAN						X	X	X	X	X	X	X	X
026-25558-000	FAN,PROP,24DIA,4BL,32DEG	PWR EXH FAN	X	X	X	X	X	X	X	X	X	X	X	X	X
026-35464-000	FILTER,SOLID CORE		X	X	X	X	X	X	X	X	X	X	X	X	X
026-38362-000	GUARD,COIL,WIREFORM		X	X	X	X	X	X	X	X	X	X	X	X	X
026-38363-000	GUARD,COMP,WIREFORM		X	X	X	X	X	X	X	X	X	X	X	X	X
026-34562-000	GUARD,FAN CONDENSER		X	X	X	X	X								
026-31435-000	GUARD,FAN, CONDENSER							X	X	X	X	X	X	X	X
025-27709-001	HEATER,ELEC,18,0KW,240/		X			X		X				X			
025-27709-002	HEATER,ELEC,18,0KW,480/			X			X		X				X		
025-27709-003	HEATER,ELEC,18,0KW,600/				X			X				X			X
025-27709-004	HEATER,ELEC,36,0KW,240		X			X		X				X			
025-27709-005	HEATER,ELEC,36,0KW,480			X			X		X				X		
025-27709-006	HEATER,ELEC,36,0KW,600/				X			X				X			X
025-27709-007	HEATER,ELEC,54,0KW,240/		X			X		X				X			
025-27709-008	HEATER,ELEC,54,0KW,480/			X			X		X				X		
025-27709-009	HEATER,ELEC,54,0KW,600/				X			X				X			X
025-27709-010	HEATER,ELEC,72,0KW,240/		X			X		X				X			
025-27709-011	HEATER,ELEC,72,0KW,480/			X			X		X				X		
025-27709-012	HEATER,ELEC,72,0KW,600/				X			X				X			X
025-29012-004	IGNITION CONTROL	IC1, IC2	X	X	X	X	X	X	X	X	X	X	X	X	X
025-27731-002	IGNITOR, SPARK W/O TERM	SPARK	X	X	X	X	X	X	X	X	X	X	X	X	X
2EE04703524	KIT,ECON SINGLE ENTHALPY		X	X	X	X	X	X	X	X	X				
2EE04703624	KIT,ECON SINGLE ENTHALPY											X	X	X	X
2MD04703524	KIT,MOTORIZED DAMPER		X	X	X	X	X	X	X	X					
2MD04703624	KIT,MOTORIZED DAMPER											X	X	X	X
035-18862-000	LABEL, WIRING MTRZD DMPR		X	X	X	X	X	X	X	X	X	X	X	X	X
035-18484-000	LABEL, WIRING MAGNUM		X	X	X	X	X	X	X	X	X	X	X	X	X
035-18526-000	LABEL, WIRING, E18 230V		X			X		X				X			
035-18530-000	LABEL, WIRING, E18 460V			X		X			X				X		
035-18534-000	LABEL, WIRING, E18 575V				X			X				X			X
035-18527-000	LABEL, WIRING, E36 230V		X			X		X				X			
035-18531-000	LABEL, WIRING, E36 460V			X		X			X				X		
035-18535-000	LABEL, WIRING, E36 575V				X			X				X			X
035-18528-000	LABEL, WIRING, E54 230V		X			X		X				X			
035-18532-000	LABEL, WIRING, E54 460V			X		X			X				X		
035-18536-000	LABEL, WIRING, E54 575V				X			X				X			X
035-18529-000	LABEL, WIRING, E72 230V		X			X		X				X			
035-18533-000	LABEL, WIRING, E72 460V			X		X			X				X		
035-18537-000	LABEL, WIRING, E72 575V				X			X				X			X
029-20081-000	MANIFOLD,GAS		X	X	X	X	X	X	X	X	X	X	X	X	X
024-24104-000	MOTOR, 3/4HP,3SPEED	POWER EXH 230V	X			X		X				X			
024-24131-000	MOTOR, 3/4HP,3 SPEED	POWER EXH 460V		X		X			X				X		
024-24104-001	MOTOR, 3/4HP 575V 3 SPD	POWER EXH 575V			X			X				X			X
024-31411-000	MOTOR, 5.0HP,575,HI EFF	ID FAN			X										
024-27617-000	MOTOR, 7.5HP, 575	ID FAN					X					X			
024-27524-000	MOTOR,BLOWER 5.0HP,208/230	ID FAN	X	X											
024-27525-000	MOTOR,BLOWER 7.5HP,230/460	ID FAN				X	X		X	X					
024-27591-004	MOTOR,BLOWER 15HP 230/460	ID FAN										X	X		
024-27591-005	MOTOR,BLOWER 15HP 575V	ID FAN													X
024-31945-006	MOTOR,FAN,1/3HP,230-1-60	OD FAN	X			X									
024-31945-005	MOTOR,FAN,1/3HP,460-1-60	OD FAN		X			X								
024-31945-004	MOTOR,FAN,1/3HP,575-1-60	OD FAN			X			X							
024-32031-001	MOTOR,FAN 1/2HP 208/230V	OD FAN						X				X			
024-32031-002	MOTOR,FAN 1/2HP,460V	OD FAN							X				X		
024-32031-003	MOTOR,FAN 1/2HP,575V	OD FAN								X					X
024-25005-001	MOTOR,VENTOR,208/230 V	DRAFT MOTOR	X			X		X				X			
024-25005-004	MOTOR,VENTOR,460V	DRAFT MOTOR		X	X		X	X	X	X	X	X	X	X	X
026-38368-000	MOUNT,MOTOR,WIREFORM,30"		X	X	X	X	X	X	X	X	X	X	X	X	X
029-20423-030	ORIFICE,GAS,BURNER,#30	PILOT	X	X	X	X	X	X	X	X	X	X	X	X	X
029-20422-058	ORIFICE,GAS,PILOT,#58	8 TUBE HEAT EXCHANGER	X	X	X	X	X	X	X	X	X	X	X	X	X
029-20422-065	ORIFICE,GAS,PILOT,#65	6 TUBE HEAT EXCHANGER	X	X	X	X	X	X	X	X	X	X	X	X	X
025-31987-000	OUTLET, CONVENIENCE	CONV OUTLET	X	X	X	X	X	X	X	X	X	X	X	X	X
029-22199-000	PIN HINGE BRASS		X	X	X	X	X	X	X	X	X	X	X	X	X

* See UNIT NAMEPLATE or TECHNICAL LITERATURE for the required breaker/max fuse size.

Part Number	Description	Notes or code on wiring diagram	Model and Voltage											
			DW-15			DW-18			DW-20			DW-25		
			230V	460V	575V	230V	460V	575V	230V	460V	575V	230V	460V	575V
024-23972-000	RELAY,CONT 24V50/60HZDPDT	DMR (Gas Units)	X	X	X	X	X	X	X	X	X	X	X	X
024-24111-000	RELAY,CONT 24V50/60HZDPST	RW1 (Gas Units)	X	X	X	X	X	X	X	X	X	X	X	X
024-21678-000	RELAY,CONT 24V50/60HZSPDT	RW2 (Gas Units)	X	X	X	X	X	X	X	X	X	X	X	X
024-24103-000	RELAY,CONT 24V50/60HZSPST	RW1, RW2, HR (Elec Heat Units)	X	X	X	X	X	X	X	X	X	X	X	X
024-27552-001	RELAY,OVL.D, 5.0- 8.0FLA	BOR		X	X					X				
024-27552-002	RELAY,OVL.D, 8.0-13.0FLA	BOR					X			X				
024-27552-003	RELAY,OVL.D,12.0-20.0FLA	BOR	X											X
024-27552-004	RELAY,OVL.D,16.0-25.0FLA	BOR				X			X				X	
024-27552-005	RELAY,OVL.D,30.0-50.0FLA	BOR										X		
025-27731-001	SENSOR, FLAME W/TERM	SENSOR	X	X	X	X	X	X	X	X	X	X	X	X
001-07117-000	SHAFT,BLOWER,15" WHEEL		X	X	X									
001-07116-000	SHAFT,BLOWER,18" WHEEL					X	X	X	X	X	X			
001-07119-000	SHAFT,BLOWER,18" WHEEL											X	X	X
028-13329-000	SHEAVE,FXD,1GRV	HI SPEED DRIVE										X	X	X
028-13330-000	SHEAVE,FXD,1GRV	STANDARD DRIVE										X	X	X
028-10564-000	SHEAVE,FXD,1GRV,1.000BORE	HI SPEED DRIVE	X	X	X									
028-12026-000	SHEAVE,FXD,1GRV,1.000BORE	STANDARD DRIVE	X	X	X									
028-10577-000	SHEAVE,FXD,1GRV,1.188BORE	STANDARD DRIVE				X	X	X	X	X	X	X	X	X
028-12012-000	SHEAVE,FXD,1GRV,1.188BORE	HI SPEED DRIVE				X	X	X	X	X	X	X	X	X
028-14721-000	SHEAVE,VAR,1GRV											X	X	X
028-04761-000	SHEAVE,VAR,1GRV,1.125BORE		X	X	X									
028-12010-000	SHEAVE,VAR,1GRV,1.375BORE					X	X	X	X	X	X	X	X	X
029-22196-000	SMOKE DETECTOR ACCESSORY	SUPPLY AIR OR RET. AIR W/ECON	X	X	X	X	X	X	X	X	X	X	X	X
026-25563-000	SUPPORT, FAN	PWR EXH FAN	X	X	X	X	X	X	X	X	X	X	X	X
025-32677-000	SWITCH, DISCONNECT, 250A, 600V	DS1												
025-17620-025	SWITCH, HI PRESSURE	HPS	X	X	X	X	X	X	X	X	X	X	X	X
024-26065-000	SWITCH, TOGGLE (CONV. OUTLET)	SW4	X	X	X	X	X	X	X	X	X	X	X	X
025-26392-007	SWITCH,LIMIT	TLS ELEC HT (CONTROL VOLTAGE)				X			X			X		
025-26392-004	SWITCH,LIMIT (60TX11)	TLS ELEC HT (CONTROL VOLTAGE)	X	X	X		X	X		X	X		X	X
025-27743-001	SWITCH,LIM.HLX,170/120DEG	TLS ELEC HT (LINE VOLTAGE)	X	X			X			X			X	
025-27743-002	SWITCH,LIM.HLX,200/150DEG	TLS ELEC HT (LINE VOLTAGE)				X			X			X		
025-30249-000	SWITCH,LOW PRESSURE	LPS	X	X	X	X	X	X	X	X	X	X	X	X
025-27755-000	TERM BLOCK, 3P,250V,20A	TB4	X	X	X	X	X	X	X	X	X	X	X	X
025-20710-000	TERM BLOCK, 3P,600V,175A	TB1												
025-20573-000	TERM BLOCK, 3P,600V,335A	TB1												
024-26089-000	TIME DELAY, DRAFT MOTOR CONTROL	DMC	X	X	X	X	X	X	X	X	X	X	X	X
025-25973-000	TRANSFORMER .075KVA 208/230-24	T2 & T3	X			X			X			X		
025-25974-000	TRANSFORMER .075KVA 460PRI-24	T2 & T4		X			X			X			X	
025-17636-000	TRANSFORMER .15KVA 240/480	T4			X		X			X				X
025-32762-000	TRANSFORMER 3KVA 240/480	T5		X			X			X			X	
025-30383-000	TRANSFORMER 3KVA 600 PRI	T5			X		X			X				X
025-37378-000	TRANSFORMER 150K VA 208/230-24	T1	X			X			X			X		
025-37378-002	TRANSFORMER 150K VA 460/575-24	T1		X	X		X	X		X	X		X	X
025-32672-240	TRANSFORMER 208/230-120V	T5	X			X			X			X		
025-27729-000	TRANSFORMER, 575V/24V 75A	T2 & T3			X			X		X				X
029-20099-000	TUBE,CARRYOVER	8 TUBE HEAT EXCHANGER	X	X	X	X	X	X	X	X	X	X	X	X
029-20404-000	TUBE,CARRYOVER	6 TUBE HEAT EXCHANGER	X	X	X	X	X	X	X	X	X	X	X	X
025-27720-000	VALVE,GAS,36C68-466	GV1 & GV2	X	X	X	X	X	X	X	X	X	X	X	X
022-06852-001	VALVE,THERMAL EXPANSION					X	X	X	X	X	X			
022-08998-000	VALVE,THERMAL EXPANSION											X	X	X
022-09013-001	VALVE,THERMAL EXPANSION		X	X	X									
026-25529-004	WHEEL,BLO,15DIA,15W,1.0BORE	ID BLOWER	X	X	X									
026-25529-003	WHEEL,BLO,18DIA,15W,1.2BORE	ID BLOWER				X	X	X	X	X	X			
026-32631-000	WHEEL,BLO,18DIA,15W,1.4BORE	ID BLOWER										X	X	X
026-32626-000	WHEEL,BLO,4DIA,2WD,375BORE	DRAFT INDUCER WHEEL	X	X	X	X	X	X	X	X	X	X	X	X
026-32625-000	WHEEL,BLO,4DIA,2WD,.375BORE	DRAFT INDUCER WHEEL	X	X	X	X	X	X	X	X	X	X	X	X

* See UNIT NAMEPLATE or TECHNICAL LITERATURE for the required breaker/max fuse size.