



Source 1
REPLACEMENT PARTS

BA-15 Ton
Single Package Heat Pump

Supersedes: Nothing

035-19287-001 Rev. A (0103)

Note: This is a non-comprehensive parts list intended for stocking purposes for first production (style A) units based on current production. It is not intended to replace the comprehensive list with subsequent changes.

Common Parts

Description	PartNumber		15 Ton
BASE,HEAT SECT,FRONT INS	373-06317-131		1
BASE,CONDENSER	373-11172-235		1
BASE,EVAPORATOR REAR L.H.	373-06208-205		1
BASE,EVAPORATOR,FRONT	373-06208-107		1
BASE,EVAPORATOR,REAR	373-06317-111		1
BASE,EVAPORATOR,REAR R/H	063-94948-000		1
BASE,HEAT SECT,REAR	373-06317-215		1
BASE,HEAT SECT,MIDDLE	373-06317-225		1
BRACKET,POST	073-23132-000		6
BRACKET,FILTER	029-20403-700		1
BRACKET,FILTER,RH	073-21724-000		1
BRACKET,FILTER,LH	373-21218-700		1
CAP,ROOF	063-94959-700		3
COVER,DUCT	373-06317-241		1
FILTER,AIR 2 X 18 X 24	026-25534-000		5
PAN,CONDENSATE	373-05199-004		1
PANEL,CORNER,FRONT	373-06208-230		1
PANEL,ACCESS,CONTROLS	073-01922-001		1
PANEL,ACCESS,HEAT SECT.,FRONT & REAR	373-06208-190		2
PANEL,ACCESS,FRESH AIR REAR	373-06208-220		1
PANEL,ACCESS,FILTER & MOTOR	373-06208-180		2
PANEL,ACCESS,FRESH AIR,EVAPORATOR END	373-06208-210		1
PANEL,ACCESS,LEFT FRONT	373-06208-170		1
PANEL,ACCESS,COMPRESSOR, TOP	073-19228-000		1
PANEL,ACCESS,COMPRESSOR,BOTTOM	073-19251-001		1
PANEL,CORNER,REAR	373-06208-200		1
PLATE,LATCH	073-01920-000		13
POST,CORNER,POWER DISCONNECT	073-15292-004		1
POST,CORNER,REAR	073-02033-000		1
POST,FRAME	073-26035-001		4
POST,FRAME,INNER	073-01987-700		8
POST,FRAME,OUTER	073-01986-700		4
RACK,FILTER	073-21725-000		3
RAIL,BASE,EVAPORATOR	073-10807-700		1
RAIL,BASE,FRONT	073-01937-700		1
RAIL,BASE,REAR	073-01938-700		1
RAIL,BASE,CONDENSOR	073-10757-700		1
RAIL, TOP	073-01981-700		2
RAIL, TOP, EVAPORATOR END	063-94943-700		1
ROOF,CONDENSER,FRONT	063-93750-000		1
ROOF,CONDENSER,REAR	063-93751-000		1

Compressors including Crankcase Heaters

Note: Voltage Code - 10th Character in Model Nomenclature

Code 2 - 208/230-3-60

COMPRESSOR,H20R813DBLA	015-03517-004		2
HEATER,CRANKCASE, 240-1-60V	025-37399-240		2

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

Compressors including Crankcase Heaters cont.**Code 4 - 460-3-60**

COMPRESSOR,H20R813DBEA	015-03518-004		2
HEATER,CRANKCASE, 480-1-60V	025-37399-480		2

Code 5 - 575-3-60

COMPRESSOR,H20R813DBFA	015-03519-004		2
HEATER,CRANKCASE, 575-1-60V	025-37399-575		2

Code 7 - 380/415-3-60

COMPRESSOR,H20R943DBEA	015-03416-004		2
HEATER,CRANKCASE, 480-1-60V	025-37399-480		2

Compressor Mounting Components

SCREW,TAPPING W/SLEEVE	021-17116-000		8
GROMMET,RUBBER	028-13344-000		8

Blower, Evaporator**Motors - Including Sheaves and Belts**

Note: Motor Selection uses **9th and 10th Characters** in Model Nomenclature

Standard Motor - 9th Character **A, B, C, D, E, F, G, H, J, K, L, or M**

208/230-3-60 10th Character Voltage Code- 2

MOTOR,BLOWER,5HP,230/460	024-27591-001		1
SHEAVE,FIXED,1GRV,1.000BORE	028-12026-700		1
SHEAVE,VARIABLE,1GRV,1.125BORE	028-04761-700		1
BELT,V BX70 71.8	028-12027-700		1
CONTACTOR,ELEC,30 AMP	024-25955-000		1
FUSEHOLDER,#19,250V,30 AMP,3P	025-18281-000		1
FUSE,DUAL,250V,30A,	025-04649-000		3
RELAY,OVERLOAD,12.0-20.0FLA	024-27552-003		1

460-3-60 10th Character Voltage Code-4

MOTOR,BLOWER 5HP,230/460	024-27591-001		1
SHEAVE,FIXED,1GRV,1.000BORE	028-12026-700		1
SHEAVE,VARIABLE,1GRV,1.125BORE	028-04761-700		1
BELT,V BX70 71.8	028-12027-700		1
CONTACTOR,ELEC,30 AMP	024-25955-000		1
FUSEHOLDER,#23,600V,30A,3P	025-18284-000		1
FUSE,DUAL,600V,12A	025-06079-000		3
RELAY,OVERLOAD	024-27552-001		1

575-3-60 10th Character Voltage Code-5

MOTOR,BLOWER,5HP,575	024-27591-002		1
SHEAVE,FIXED,1GRV,1.000BORE	028-12026-700		1
SHEAVE,VARIABLE,1GRV,1.125BORE	028-04761-700		1
BELT,V BX70 71.8	028-12027-700		1
FUSEHOLDER,#23,600V,30A,3P	025-18284-000		1
FUSE,DUAL,600V,12AMP	025-06079-000		3
RELAY,OVERLOAD	024-27552-001		1

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

Motors - Including Sheaves and Belts cont.

380/415-3-50 10th Character **Voltage Code-7**

MOTOR,BLOWER,5HP,230/460	024-27591-001		1
SHEAVE,FIXED,1GRV,1.000BORE	028-10564-700		1
SHEAVE,VARIABLE,1GRV,1.125BORE	028-04761-700		1
BELT,V BX68 69.8	028-10382-700		1
CONTACTOR,ELEC,30 AMP	024-25955-000		1
FUSEHOLDER,#19,250V,30 AMP,3P	025-18281-000		1
FUSE,DUAL,250V,30 AMP	025-04649-000		3
RELAY,OVERLOAD,12.0-20.0FLA	024-27552-003		1

Common Parts, Evaporator Blower

HOUSING,15 IN. WHEEL	073-01951-000		1
PLATE,TOP,15 IN. BLOWER	063-89998-000		1
PLATE,BOTTOM,15 IN. BLOWER	063-89999-000		1
WHEEL,BLOWER	026-25529-704		1
SHAFT,BLOWER	001-07117-000		1
BEARING,BALL,PILLOW BLOCK	029-20424-700		2
KEY,STL,1/4 SQ X 6.375 LG	001-07110-004		1
KEY,STL,1/4 SQ X 2.000 LG	001-07110-005		1
SUPPORT,BEARING	063-89950-000		2
BRACKET,TENSIONER	063-94940-000		1
SUPPORT,MOTOR	063-94674-000		1
SUPPORT,MOTOR	073-01954-000		1

CONDENSER FAN

Note: Motor Selection uses **10th Character** in Model Nomenclature

208/230-3-60 10th Character **Voltage Code- 2**

MOTOR,FAN,CONDENSER	024-31939-002		2
---------------------	---------------	--	---

460-3-60 10th Character **Voltage Code-4**

MOTOR,FAN,CONDENSER	024-31939-002		2
---------------------	---------------	--	---

575-3-60 10th Character **Voltage Code-5**
Electric Heat

MOTOR,FAN,CONDENSER	024-31939-003		2
---------------------	----------------------	--	---

380/415-3-50 10th Character **Voltage Code-7**

MOTOR,FAN,CONDENSER	024-31939-003		2
---------------------	----------------------	--	---

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

Common Parts, Condenser Fan

SUPPORT,MOTOR	026-37389-000		2
GUARD,FAN	026-25549-000		2
ORIFICE,FAN	063-94820-000		2
CLAMP,MOTOR	026-25568-000		2
FAN,PROP,30DIA,3BL,18DEG	026-25579-000		2
CONTACTOR,ELEC	024-24101-700		2

ELECTRICAL BOX

Note: Refer to **Voltage Code - 10th Character** for components.

AIR ONLY UNITS - 6TH CHARACTER - C**380-3-60 10th Character Voltage Code- 3**

CIRCUIT BREAKER,3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER,6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC,40 AMP	024-25844-000	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMP SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL, 600V1 1/2A,	025-27750-000	(FU16,17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, .075KVA 460	025-27732-000	(T2)	1
TRANSFORMER, .50K VA 380/415-24	025-37378-001	(T1)	1

575-3-60 10th Character Voltage Code- 5

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC,30 AMP	024-25955-000	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMP SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL, 600V1 1/2A,	025-27750-000	(FU16,17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,600V 30A,13X16X5	025-04650-000	(FU1-3)	3
FUSEHOLDER,#23,600V, 30A,3P	025-18284-000		1
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
TERMINAL BLOCK, 3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK, 3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, 575V/24V 75A	025-27729-700	(T2)	1
TRANSFORMER,150K VA 208/230-24	025-37378-002	(T1)	1

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

ELECTRICAL BOX cont.

380/415-3-50 10th Character Voltage Code- 7

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC 3P 40A	024-25844-700	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMP SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL,600V1 1/2A,	025-27750-000	(FU16,17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER,75VA	025-27732-700	(T2)	1
TRANSFORMER,.150K VA 380/415-24	025-37378-001	(T1)	1

ELECTRIC HEAT UNITS - 6TH CHARACTER - E

208/230-3-60 10th Character Voltage Code- 2

36 KW HEAT

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC 3P 40A	024-25844-700	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMPERATURE,SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL,600V1 1/2A,	025-27750-000	(FU16-17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,250V 60A,13X16X3	025-13292-000	(FU1-6)	6
FUSEHOLDER,#20,250V, 60A,3P	025-18283-000		2
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(HR)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(RW2)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(MV1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, .075KVA 208/230-24	025-25973-700	(T2)	1
TRANSFORMER,150K VA 208/230-24	025-37378-000	(T1)	1

54 KW HEAT

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR ELEC 3P 40A	024-25844-700	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMPERATURE,SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL,600V1 1/2A,	025-27750-000	(FU16-17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,250V 60A,13X16X3	025-13292-000	(FU1-6)	6
FUSEHOLDER,#20,250V, 60A,3P	025-18283-000		2
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(HR)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(RW2)	1

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

ELECTRIC HEAT UNITS - 6TH CHARACTER - E - Cont.

54 KW HEAT cont.

RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(MV1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, .075KVA 208/230-24	025-25973-700	(T2)	1
TRANSFORMER,150K VA 208/230-24	025-37378-000	(T1)	1

460-3-60 10th Character Voltage Code- 4

36 KW HEAT

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC,30 AMP	024-25955-000	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMPERATURE,SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL, 600V1 1/2A,	025-27750-000	(FU16-17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,600V60A,1 1/6 X	025-17392-000	(FU1-3)	3
FUSEHOLDER,#24,600V,60A,3	025-18285-000		1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(HR)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(RW2)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(MV1)	1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
LUG,ELEC 14 -1/0	025-19282-000		1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, .075KVA 208/230-24	025-25974-700	(T2)	1
TRANSFORMER,150K VA 208/230-24	025-37378-000	(T1)	1

54 KW HEAT

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC 3P 40A	024-25955-000	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMPERATURE,SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL, 600V1 1/2A,	025-27750-000	(FU16-17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,600V 60A,13X16X3	025-04650-000	(FU1-3)	3
FUSEHOLDER,#20,250V, 60A,3P	025-18284-000		1
FUSE,DUAL,600V,60A	025-17392-000	(FU4-6)	3
FUSEHOLDER,#24,600V,60A,3P	025-18285-000		1
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(HR)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(RW2)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(MV1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, .075KVA 208/230-24	025-25974-700	(T2)	1
TRANSFORMER,150K VA 208/230-24	025-37378-000	(T1)	1

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

575-3-60 10th Character Voltage Code- 5

36 KW HEAT

CIRCUIT BREAKER 3.2A 250V	024-31976-000	(CB2)	1
CIRCUIT BREAKER 6A 250V	024-27583-000	(CB1)	1
CONTACTOR,ELEC.30 AMP	024-25955-000	(M1,2)	2
CONTROL,DEFROST	031-09104-000	(DC1,2)	2
CONTROL,SIMPLICITY,LOCKOUT	031-01934-001		1
CONTROL,TEMPERATURE,SPST 30F	025-35355-001	(LAS3)	1
FUSE,DUAL, 600V1 1/2A,	025-27750-000	(FU16,17)	2
FUSEHOLDER,# 1,600V, 30A,1P	025-17407-000		2
FUSE,DUAL,600V60A,1 1/6 X	025-17392-000	(FU1-3)	3
FUSEHOLDER,#24,600V,60A,3_	025-18285-000		1
LUG,ELEC 14 -1/0	025-19282-000		1
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(EH1,2)	2
RELAY,CONTROL,24V50/60HZDPDT	024-23972-000	(RW1)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(HR)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(RW2)	1
RELAY,CONTROL,24V50/60HZSPST	024-24103-000	(MV1)	1
TERMINAL BLOCK,3P,250V 20A	025-27755-000	(TB4)	1
TERMINAL BLOCK,3P,600V,175A	025-20710-000	(TB1)	1
TRANSFORMER, 575V/24V 75A	025-27729-700	(T2)	1
TRANSFORMER,.150KVA 460/575-24	025-37378-002	(T1)	1

CONDENSER COIL

COIL,CONDENSER	373-10901-700		1
DISTRIBUTOR ASSY,TXV	022-08939-000		1
HEADER,CONDENSER	373-10901-030		1
COIL,CONDENSER	373-10794-700		1
DISTRIBUTOR ASSY,TXV	022-08939-000		2
HEADER,CONDENSER	373-10794-730		1

EVAPORATOR COIL

COIL,EVAPORATOR	373-19220-001		1
DISTRIBUTOR ASSY,TXV, 6 TUBE	022-08941-700		2
HEADER, ASSY,SYS 1	373-19220-050		1
HEADER ASSY,SYS 2	373-19220-060		1

PIPING COMPONENTS

FILTER DRIER,HEAT PUMP	029-20485-700		2
CAP,SEAL 1/4 FLARE	023-10745-000		4
CORE,V PORT /SCHRAEDER	022-02475-700		4
ACCUMULATOR,182/ 12.9	026-31431-000		2
VALVE,REVERSING	025-33379-000		2
VALVE,TXV	025-38229-000		2
VALVE,CHECK	022-08938-700		4
STEM,VALVE, 1/4 OD VALVE	022-08017-000		4

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

ELECTRIC HEAT

36 KW HEAT

208/230-3-60 10th Character Voltage Code- 2

HEATER,ELEC,36.0KW,240	025-27709-004		1
CONTACTOR,ELEC 3P 40A	024-25844-700		2
SWITCH,LIMIT,100/120 60TX	025-26392-704		2
SWITCH,LIMIT,HLX,170/120DEG	025-27743-001		2

460-3-60 10th Character Voltage Code- 4

HEATER,ELEC,36.0KW,480	025-27709-705		1
CONTACTOR,ELEC,30 AMP	024-25955-000		2
SWITCH,LIMIT,100/120 60TX	025-26392-704		2
SWITCH,LIMIT,HLX,170/120DEG	025-27743-001		2

575-3-60 10th Character Voltage Code- 5

HEATER,ELEC,36.0KW,600/	025-27709-006		1
CONTACTOR,ELEC,30 AMP	024-25955-000		2
SWITCH,LIMIT,100/120 60TX	025-26392-704		2

54 KW HEAT

208/230-3-60 10th Character Voltage Code- 2

HEATER,ELEC,54.0KW,240/	025-27709-007		1
CONTACTOR,ELEC 3P 40A	024-25844-700		3
SWITCH,LIMIT 100/120 60TX	025-26392-704		2
SWITCH,LIMIT,HLX,170/120DEG	025-27743-001		3

575-3-60 10th Character Voltage Code- 5

HTR,ELEC,54.0KW,480/	025-27709-008		1
CONTACTOR,ELEC,30 AMP	024-25955-000		1
SWITCH,LIMIT,100/120 60TX	025-26392-704		2
SWITCH,LIMIT,HLX,170/120DEG	025-27743-001		2
CONTACTOR,ELEC 3P 40A	024-25844-700		1

DISCONNECT SECTION

With Disconnect - 11th Character B, D, G, H, J, K, L, or M

240 Volt

CIRCUIT BREAKER,60A,240V	024-26069-000		1
--------------------------	---------------	--	---

460 Volt

CIRCUIT BREAKER,45A,480V	024-27643-000		1
--------------------------	---------------	--	---

575 Volt

CIRCUIT BREAKER,35A,600V	024-27574-000		1
--------------------------	---------------	--	---

Without Disconnect - 11th Character A, C, E, F, N, P, Q, R

PLATE,PATCH,DISCONNECT	073-22688-001		1
------------------------	---------------	--	---

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

CONVENIENCE OUTLET

With Convenience Outlet - 11 Character C, D, J, K, M, N, P, Q

Non-Powered

OUTLET,CONVENIENCE	025-31987-000		1
--------------------	---------------	--	---

Powered

230 Volt

TRANSFORMER,208/230-120V	025-32672-240		1
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2
FUSE,600V,30A	025-32733-001		2
CIRCUIT BREAKER,20A,250V	024-27517-000		1
OUTLET,CONVENIENCE	025-31987-000		1

460 Volt

TRANSFORMER,3KVA,240/480	025-32762-000		1
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2
FUSE,600V,30A	025-32733-001		2
CIRCUIT BREAKER,20A,250V	024-27517-000		1
OUTLET,CONVENIENCE	025-31987-000		1

575 Volt

TRANSFORMER,3KVA	025-30383-000		1
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2
FUSE,600V,30A	025-32733-001		2
CIRCUIT BREAKER,20A,250V	024-27517-000		1
OUTLET,CONVENIENCE	025-31987-000		1

Without Convenience Outlet - 11 Character is A, B, E, F, G, H, L, R

PLATE,OUTLET,COVER	073-22964-000		
--------------------	---------------	--	--

SMOKE DETECTOR

SUPPLY AIR -

With Smoke Detector - 11th Character E, G, J, L, M, N, Q, R

SMOKE DETECTOR KIT	029-22280-000		
--------------------	---------------	--	--

No Smoke Detector - 11th Character A, B, C, D, F, H, K, P

HARNES,JUMPER,SUPPLY AIR	025-35366-009		1
--------------------------	----------------------	--	---

New replacement parts shown in **bold face** at the first printing of the parts list code dated (0103)

RETURN AIR**With Smoke Detector & Economizer - 11th Character H, L, M, P, Q, R**

SMOKE DETECTOR	029-22280-000		1
----------------	---------------	--	---

With Smoke Detector, No Economizer - 11th Character F, K

SMOKE DETECTOR	029-22196-000		1
----------------	---------------	--	---

No Smoke Detector - 11th Character A, B, C, D, E, G, J, N

HARNESS,JUMPER,RETURN AIR	025-35366-009		1
---------------------------	----------------------	--	---

PHASE MONITOR**6.5 & 12.5 T Units - Standard****7.5, 8.5 & 10.0 T Units - 12th and 13th Characters - AB, TB & AG**

PHASE,MONITOR,0-600V	031-01922-000		1
----------------------	---------------	--	---

COIL GUARD**All Units - 12th and 13th Characters - AC, AE, AG, AH, CG, TC**

COIL GUARD	026-35597-001		1
COIL GUARD	026-35597-002		1

DIRTY FILTER SWITCH (Except BAS Units - See Below)**7.5 T Units - 12th and 13th Characters - AD, AG**

SWITCH,AIR PROVING	031-01123-700		1
--------------------	---------------	--	---