



Source 1
Replacement Parts

Supersedes : 035-19410-001-C-0303

DS 3 thru 5 Ton

Gas / Electric Straight Cooling AC
Mid-Efficiency
035-19410-002-D-0603

Note: This is a non-comprehensive parts list intended for stocking purposes for first production (style A) units based on current production. It is not intended to replace the comprehensive list with subsequent changes.

COMMON PARTS

| | | |
|---------------------------|----------------------|---|
| BRACKET,FILTER,MIDDLE | 029-18446-000 | 1 |
| BRACKET,FILTER,BOTTOM | 029-18447-000 | 1 |
| RAIL,BASE | 063-87534-001 | 2 |
| RAIL,END | 063-87544-001 | 1 |
| RAIL,END | 063-89741-000 | 1 |
| PANEL,COMPRESSOR ACCESS | 063-87559-000 | 1 |
| POST,CORNER,FRONT | 063-87617-000 | 1 |
| POST,CORNER,REAR | 063-87618-000 | 1 |
| PANEL,BAFFLE,FILTER,LH | 073-21209-000 | 1 |
| BRACKET, TOP | 073-21697-000 | 1 |
| BRACKET,BASE | 073-21698-000 | 1 |
| COVER,DUCT | 363-87667-101 | 3 |
| COVER, BASE DUCT | 363-89742-000 | 1 |
| COVER,BASE DUCT | 373-03111-000 | 1 |
| PANEL,BLOWER SECTION | 373-03098-100 | 1 |
| ROOF,EVAPORATOR | 373-03102-102 | 1 |
| PAN,CONDENSATE,STANDARD | 363-87677-000 | 1 |
| PAN,CONDENSATE | 063-94795-001 | 1 |
| ELBOW,90 DEGREE,PVC | 023-13649-000 | 1 |
| BUSHING,CONDUIT | 025-26385-000 | 1 |
| PAN,CONDENSATE,DOWN DRAIN | 363-87677-001 | 1 |
| PAN,CONDENSATE | 063-94795-002 | 1 |
| ADAPTER,PVC,3/4SLP | 023-16807-000 | 1 |
| BUSHING,CONDUIT | 025-26385-000 | 1 |
| ROOF,CONDENSER | 063-94761-700 | 1 |

CABINET OPTIONS

Standard Cabinet

Cooling/Elec Heat

| | | |
|----------------------------|----------------------|---|
| PANEL,FILTER SECTION | 363-87539-700 | 1 |
| POST,CABINET | 073-26149-001 | 1 |
| PANEL,DUCT | 373-03097-000 | 1 |
| PANEL,ACCESS,ELECTRIC HEAT | 373-03088-001 | 1 |

Gas Heat

| | | |
|----------------------|---------------|---|
| PANEL,FILTER SECTION | 363-87539-700 | 1 |
|----------------------|---------------|---|

| | | |
|-----------------------|----------------------|---|
| POST,CABINET | 073-26149-001 | 1 |
| PANEL,DUCT | 373-03097-000 | 1 |
| PANEL,ACCESS,GAS HEAT | 073-05379-001 | 1 |

**Toolless Cabinet
Cooling/Elec Heat**

| | | |
|----------------------------|----------------------|----|
| PANEL,FILTER ACCESS | 373-20676-000 | 1 |
| POST,CABINET | 073-26149-002 | 1 |
| PANEL,DUCT | 373-14781-206 | 1 |
| PANEL,ACCESS,ELECTRIC HEAT | 373-03088-002 | 1 |
| PLATE,LATCH | 073-01920-000 | 2 |
| PLATE,LATCH | 073-01931-000 | 7 |
| KNOB,TEE STUD | 029-22127-000 | 11 |

Gas Heat

| | | |
|-----------------------|----------------------|----|
| PANEL,FILTER ACCESS | 373-20676-000 | 1 |
| POST,CABINET | 073-26149-002 | 1 |
| PANEL,DUCT | 373-14781-206 | 1 |
| PANEL,ACCESS,GAS HEAT | 073-05379-002 | 1 |
| PLATE,LATCH | 073-01920-000 | 2 |
| PLATE,LATCH | 073-01931-000 | 7 |
| KNOB,TEE STUD | 029-22127-000 | 11 |

FILTERS

| | | |
|----------------------------|----------------------|---|
| FILTER,AIR,1X14X25 | 026-10019-000 | 1 |
| FILTER,AIR,1X15X20 | 026-34786-000 | 2 |
| FILTER,AIR,2X14X25,PLEATED | 026-38038-000 | 1 |
| FILTER,AIR,2X15X20,PLEATED | 026-38039-000 | 2 |

COMPRESSORS

Code F - 208/230-1-60

3 Ton 4 Ton 5 Ton

| | | | | |
|----------------------------|----------------------|---|---|---|
| COMPRESSOR,H25A38QCBCA | 015-02553-701 | 1 | - | - |
| COMPRESSOR,H29A47SCBCA | 015-03520-001 | - | 1 | - |
| COMPRESSOR,ZR57K3-PFV | 015-02620-704 | - | - | 1 |
| CAPACITOR,RUN,45.0/7.5MFD | 024-25059-700 | 1 | - | - |
| CAPACITOR,RUN,55.0/7.5MFD | 024-25044-700 | - | 1 | - |
| CAPACITOR,RUN,80.0/7.5MFD | 024-25912-700 | - | - | 1 |
| CAPACITOR,START,270-324MFD | 024-25390-700 | 1 | - | - |
| START ASSIST DEVICE | 024-25398-000 | - | 1 | - |
| GROMMET | 028-12357-000 | 4 | 4 | - |
| GROMMET | 028-13344-000 | - | - | 4 |
| SPRING,COMPRESSOR MTG. | 029-20421-000 | 4 | 4 | - |

Code T - 208/230-3-60

3 Ton 4 Ton 5 Ton

| | | | | |
|------------------------|---------------|---|---|---|
| COMPRESSOR,H25A38QDBLA | 015-02554-701 | 1 | - | - |
| COMPRESSOR,H29A47SDBLA | 015-03403-001 | - | 1 | - |
| COMPRESSOR,H29A47SDBVA | 015-03404-001 | - | - | 1 |
| GROMMET | 028-12357-000 | 4 | 4 | 4 |
| SPRING,COMPRESSOR MTG. | 029-20421-000 | 4 | 4 | 4 |
| GROMMET | 028-11969-000 | 4 | 4 | 4 |

Code W - 460-3-60

3 Ton 4 Ton 5 Ton

| | | | | |
|------------------------|---------------|---|---|---|
| COMPRESSOR,H25A38QDBEA | 015-02555-701 | 1 | - | - |
| COMPRESSOR,H29A47SDBVA | 015-03404-001 | - | 1 | - |
| COMPRESSOR,ZR57K3-TFD | 015-03366-004 | - | - | 1 |
| GROMMET | 028-12357-000 | 4 | 4 | |
| GROMMET | 028-13344-000 | - | - | 4 |
| SPRING,COMPRESSOR MTG. | 029-20421-000 | 4 | 4 | - |
| GROMMET | 028-11969-000 | 4 | 4 | - |

Code X - 575-3-60

3 Ton 4 Ton 5 Ton

| | | | | |
|------------------------|---------------|---|---|---|
| COMPRESSOR,H25A38QDBFA | 015-02556-701 | 1 | - | - |
| COMPRESSOR,H29A47SDBFA | 015-03405-001 | - | 1 | |
| COMPRESSOR,ZR57KS-TFE | 015-03399-004 | - | - | 1 |
| GROMMET | 028-12357-000 | 4 | 4 | - |
| SPRING,COMPRESSOR MTG. | 029-20421-000 | 4 | 4 | - |
| GROMMET | 028-11969-000 | 4 | 4 | - |
| GROMMET | 028-13344-000 | - | - | 4 |

ELECTRICAL BOX

Cooling Only - BELT DRIVE

Code F - 208/230-1-60

3 Ton 4 Ton 5 Ton

| | | | | |
|-----------------------------|----------------------|---|---|---|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR | 024-27531-000 | 1 | 1 | - |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,40AMP | 024-25837-700 | - | - | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,,075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code T - 208/230-3-60

3 Ton 4 Ton 5 Ton

| | | | | |
|---------------------------|---------------|---|---|---|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,1P | 024-25965-000 | 1 | 1 | 1 |

| | | | | |
|-----------------------------|----------------------|---|---|---|
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMPERATURE,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code W - 460-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,2P | 024-25965-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25965-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |
| TRANSFORMER,750VA,240/480 | 025-32758-000 | 1 | 1 | 1 |

Cooling Only - DIRECT DRIVE

Code F - 208/230-1-60

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR | 024-27531-000 | 1 | 1 | - |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,40AMP | 024-25837-700 | - | - | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code T - 208/230-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code W - 460-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,1P | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP,SPST,30F | 025-35355-001 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |
| TRANSFORMER,750VA,340/480 | 025-32758-000 | 1 | 1 | 1 |

**Gas Heat - BELT DRIVE
Code F - 208/230-1-60**

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| CIRCUIT BREAKER | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR | 024-27561-000 | 1 | 1 | - |
| CONTACTOR,ELEC,20AMP,1P, | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,40AMP | 024-25837-700 | - | - | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |

| | | | | |
|-----------------------------|----------------------|---|---|---|
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code T - 208/230-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,2P | 024-25965-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code W - 460-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,2P | 024-25965-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50,60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,DPST | 024-25910-700 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP,2P | 024-25965-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP,SPST,45F | 025-35355-000 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| REALY,CONT,24V5060HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,DPST | 024-25910-700 | 1 | 1 | 1 |

| | | | | |
|----------------------------|---------------|---|---|---|
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |
| TRANSFORMER,750VA,240/480 | 025-32758-000 | 1 | 1 | 1 |

**Gas Heat - DIRECT DRIVE
Code F - 208/230-1-60**

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR | 024-27531-000 | 1 | 1 | - |
| CONTACTOR,ELEC,20AMP,1P | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,40AMP | 024-25837-700 | - | - | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code T - 208/230-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | 1 | 1 |

Code W - 460-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,DPST | 024-25910-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |

| | | | | |
|----------------------------|---------------|---|---|---|
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,460PRI | 025-25974-700 | 1 | 1 | 1 |

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| CIRCUIT BREAKER,3.2A | 024-31976-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,20AMP | 024-25964-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC,30AMP | 024-25955-000 | 1 | 1 | 1 |
| CONTROL,SIMPLICITY,LOCKOUT | 031-01934-002 | 1 | 1 | 1 |
| CONTROL,TEMP. SWITCH,SPST | 025-38585-000 | 1 | 1 | 1 |
| LUG,ELECTRICAL | 025-21798-000 | 1 | 1 | 1 |
| RELAY,CONT ,24V50/60HZ,DPST | 024-25910-000 | 1 | 1 | 1 |
| RELAY,CONT,24V50/60HZ,SPST | 024-24103-000 | 1 | 1 | 1 |
| TERMINAL BLOCK,2P,300V,20A | 025-23083-000 | 1 | 1 | 1 |
| TERMINAL,GROUNDING | 025-29006-000 | 1 | 1 | 1 |
| TIME DELAY | 024-26089-000 | 1 | 1 | 1 |
| TRANSFORMER,750VA,240/480 | 025-32758-000 | 1 | 1 | 1 |
| TRANSFORMER,75VA | 025-30728-000 | 1 | 1 | 1 |

CONDENSER COIL

| | | 3 Ton | 4 Ton | 5 Ton |
|---------------------------|----------------------|-------|-------|-------|
| COIL,CONDENSER | 373-10462-101 | 1 | 1 | - |
| COIL,CONDENSER,TECHNICOAT | 373-10462-151 | 1 | 1 | - |
| COIL,CONDENSER | 373-10495-100 | - | - | 1 |
| COIL,CONDENSER,TECHNICOAT | 373-10495-150 | - | - | 1 |
| HEADER,CONDENSER | 373-10462-040 | 1 | 1 | - |
| HEADER,DISCHARGE | 373-10462-050 | 1 | 1 | - |
| HEADER,DISCHARGE | 373-10495-030 | - | - | 1 |
| HEADER,CONDENSER | 373-10495-040 | - | - | 1 |

EVAPORATOR COIL

Belt Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| COIL,EVAPORATOR | 373-26201-010 | 1 | - | - |
| COIL,EVAP.,TECHNICOAT | 373-20276-201 | 1 | - | - |
| COIL,EVAPORATOR | 373-26201-012 | - | 1 | - |
| COIL,EVAP.,TECHNICOAT | 373-20274-201 | - | 1 | - |
| COIL,EVAPORATOR | 373-26201-014 | - | - | 1 |
| COIL,EVAP.,TECHNICOAT | 373-20275-201 | - | - | 1 |
| DISTRIBUTOR ASSY,TXV,6 TUBE | 022-08961-018 | 1 | 1 | - |
| DISTRIBUTOR ASSY,TXV,7 TUBE | 022-08961-019 | - | - | 1 |
| VALVE,EXPANSION | 025-30243-000 | 1 | - | - |
| VALVE,EXPANSION | 025-30244-000 | - | 1 | - |
| VALVE,EXPANSION | 025-30245-000 | - | - | 1 |
| SUPPORT,COIL TOP | 073-13611-000 | 1 | - | - |

| | | | | |
|----------------------|----------------------|---|---|---|
| SUPPORT,COIL TOP | 073-13610-000 | - | 1 | - |
| SUPPORT,COIL TOP | 073-13612-000 | - | - | 1 |
| HEADER,ID COIL 3 TON | 373-10681-702 | 1 | - | - |
| HEADER,ID COIL 4 TON | 373-10379-004 | - | 1 | - |
| HEADER,ID COIL 5 TON | 373-10488-002 | - | - | 1 |

Direct Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| COIL,EVAPORATOR | 373-26201-011 | 1 | - | - |
| COIL,EVAP.,TECHNICOAT | 373-10681-201 | 1 | - | - |
| COIL,EVAPORATOR | 373-26201-013 | - | 1 | - |
| COIL,EVAP.,TECHNICOAT | 373-10379-701 | - | 1 | - |
| COIL,EVAPORATOR | 373-26204-015 | - | - | 1 |
| COIL,EVAP.,TECHNICOAT | 373-10488-701 | - | - | 1 |
| DISTRIBUTOR ASSY,TXV,6 TUBE | 022-08961-008 | 1 | 1 | - |
| DISTRIBUTOR ASSY,TXV,7 TUBE | 022-08961-009 | - | - | 1 |
| VALVE,EXPANSION | 025-30243-000 | 1 | - | - |
| VALVE,EXPANSION | 025-30244-000 | - | 1 | - |
| VALVE,EXPANSION | 025-30245-000 | - | - | 1 |
| SUPPORT,COIL TOP | 073-13611-000 | 1 | - | - |
| SUPPORT,COIL TOP | 073-13610-000 | - | 1 | - |
| SUPPORT,COIL TOP | 073-13612-000 | - | - | 1 |
| HEADER,ID COIL 3 TON | 373-10681-002 | 1 | - | - |
| HEADER,ID COIL 4 TON | 373-10379-004 | - | 1 | - |
| HEADER,ID COIL 5 TON | 373-10488-002 | - | - | 1 |

PIPING

Belt Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------|---------------|-------|-------|-------|
| SWITCH,LOW PRESSURE | 025-30249-700 | 1 | 1 | 1 |
| CONTROL,PRESSURE, | 025-17620-014 | 1 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-27727-001 | 1 | 1 | 1 |
| FILTER,SOLID | 026-35463-000 | 1 | 1 | 1 |
| CORE,V PORT,SCHRAEDER | 022-02475-700 | 2 | 2 | 2 |
| CAP,SEAL,1/4 FLARE | 023-10745-000 | 2 | 2 | 2 |
| STEM,VALVE,1/4 O.D. | 022-08017-000 | 1 | 1 | 1 |

Direct Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------|---------------|-------|-------|-------|
| SWITCH,LOW PRESSURE | 025-30249-700 | 1 | 1 | 1 |
| CONTROL,PRESSURE | 025-17620-014 | 1 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-27727-001 | 1 | 1 | 1 |
| FILTER,SOLID | 026-35463-000 | 1 | 1 | 1 |
| CORE,V PORT,SCHRAEDER | 022-02475-700 | 2 | 2 | 2 |
| CAP,SEAL,1/4 FLARE | 023-10745-000 | 2 | 2 | 2 |
| STEM,VALVE,1/4 O.D. | 022-08017-000 | 1 | 1 | 1 |

BLOWER, EVAPORATOR

Belt Drive

Motors - Including Sheaves and Belts

Code F - 208/230-1-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------------|----------------------|-------|-------|-------|
| MOTOR, 1.5 HP 115/230 1PH | 024-25868-700 | 1 | 1 | 1 |
| BLOWER, BELT DRIVE, 12 X 10 | 026-25539-001 | 1 | 1 | 1 |
| SHAFT, BLOWER, 12"/15"WHEEL | 001-07115-000 | 1 | 1 | 1 |
| CAP, RUN, 25.0/ MFD, 370V | 024-23181-700 | 1 | 1 | 1 |
| BELT, V A35 36.3 | 028-09572-700 | - | - | 1 |
| BELT, V A36 37.3 | 028-09573-700 | 1 | 1 | - |
| SHEAVE, VARIABLE, 1GRV, .625BORE | 028-12361-700 | 1 | 1 | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12363-700 | - | - | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12383-700 | 1 | 1 | - |

Code T - 208/230-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------------|---------------|-------|-------|-------|
| MOTOR, BLOWER, 1.5HP, 208/460 | 024-19623-718 | 1 | 1 | 1 |
| BLOWER, BELT DRIVE, 12 X 10 | 026-25539-701 | 1 | 1 | 1 |
| SHAFT, BLOWER, 12"/15"WHEEL | 001-07115-000 | 1 | 1 | 1 |
| BELT, V A35 36.3 | 028-09572-700 | - | - | 1 |
| BELT, V A36 37.3 | 028-09573-700 | 1 | 1 | - |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12363-700 | - | - | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12383-700 | 1 | 1 | - |
| SHEAVE, VARIABLE, 1GRV, .878BORE | 028-12385-700 | 1 | 1 | 1 |

Code W - 460-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------------|----------------------|-------|-------|-------|
| MOTOR, BLOWER, 1.5HP, 208/460 | 024-19623-718 | 1 | 1 | 1 |
| BLOWER, BELT DRIVE, 12 X 10 | 026-25539-001 | 1 | 1 | 1 |
| SHAFT, BLOWER, 12"/15"WHEEL | 001-07115-000 | 1 | 1 | 1 |
| BELT, V A35 36.3 | 028-09572-700 | - | - | 1 |
| BELT, V A36 37.3 | 028-09573-700 | 1 | 1 | - |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12363-700 | - | - | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12383-700 | 1 | 1 | - |
| SHEAVE, VARIABLE, 1GRV, .878BORE | 028-12385-700 | 1 | 1 | 1 |

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------------|----------------------|-------|-------|-------|
| MOTOR, BLOWER, 1.5HP, 575V | 024-19623-707 | 1 | 1 | 1 |
| BLOWER, BELT DRIVE, 12 X 10 | 026-25539-001 | 1 | 1 | 1 |
| SHAFT, BLOWER, 12"/15"WHEEL | 001-07115-000 | 1 | 1 | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12363-700 | - | - | 1 |
| SHEAVE, FIXED, 1GRV, 1.000BORE | 028-12383-700 | 1 | 1 | - |
| SHEAVE, VARIABLE, 1GRV, .878BORE | 028-12385-700 | 1 | 1 | 1 |
| BELT, V A35 36.3 | 028-09572-700 | - | - | 1 |

| | | | | |
|-----------------|---------------|---|---|---|
| BELT,V A36 37.3 | 028-09573-700 | 1 | 1 | - |
|-----------------|---------------|---|---|---|

Common Parts - Belt Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|---------------------------|---------------|-------|-------|-------|
| KEY,STL,1/4 SQ X 4.000 LG | 001-07110-702 | 1 | 1 | 1 |
| KEY,STL,1/4 SQ X 2.000 LG | 001-07110-005 | 1 | 1 | 1 |
| BEARING,BALL PILLOW BLOCK | 029-20424-700 | 2 | 2 | 2 |
| BRACKET,BEARING SUPPORT | 073-12442-700 | 2 | 2 | 2 |
| BRACKET,MOTOR PIVOT | 073-12444-700 | 1 | 1 | 1 |
| BRACKET,MOTOR ADJUSTMENT | 073-15128-000 | 1 | 1 | 1 |

Direct Drive

Code F - 208/230-1-60

Code T - 208/230-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------------|---------------|-------|-------|-------|
| MOTOR, .75HP 230V 3 SPEED | 024-21670-001 | - | 1 | - |
| MOTOR,1HP 230V 3 SPEED | 024-21672-001 | - | - | 1 |
| MOTOR,.5HP 230V 3 SPEED | 024-24106-001 | 1 | - | - |
| CAPACITOR,RUN, 7.5/ MFD,370V | 024-20045-700 | 1 | - | - |
| CAPACITOR,RUN,12.5/ MFD,370V | 024-25899-000 | - | 1 | - |
| CAPACITOR,RUN,15.0/ MFD,370V | 024-25900-000 | - | - | 1 |

Code W - 460-3-60

Code X - 575-3-60

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------------|---------------|-------|-------|-------|
| MOTOR,3/4 HP 460V | 024-21671-002 | - | 1 | - |
| MOTOR,.5HP 460V 3 SPEED | 024-24107-001 | 1 | - | - |
| MOTOR,1HP 460V 3 SPEED | 024-25000-002 | - | - | 1 |
| CAPACITOR,RUN, 7.5/ MFD,370V | 024-20045-700 | 1 | - | - |
| CAPACITOR,RUN,25.0/ MFD,370V | 024-23181-700 | - | - | 1 |
| CAPACITOR,RUN,12.5/ MFD,370V | 024-25899-000 | - | 1 | - |

Common Parts - Direct Drive

| | | 3 Ton | 4 Ton | 5 Ton |
|--------------------------|---------------|-------|-------|-------|
| BLOWER,DIRECT DRIVE 12 X | 026-25539-700 | 1 | 1 | 1 |
| HANGER,MOTOR | 026-32681-700 | 1 | 1 | 1 |

CONDENSER FAN

Code F - 208/230-1-60

Code T - 208/230-3-60

| | | | | |
|--------------------------|---------------|---|---|---|
| MOTOR,FAN,.50HP,208/230V | 024-24110-701 | 1 | 1 | 1 |
| FAN,PROP,22DIA,3BL,34DEG | 026-32173-000 | - | 1 | 1 |
| FAN,PROP,22DIA,3BL,24DEG | 026-32175-000 | 1 | - | - |
| CAPACITOR,RUN,7.5/MFD | 024-20045-700 | 1 | 1 | 1 |

| | | | | |
|-------------------------|---------------|---|---|---|
| HARNES, FAN MOTOR | 025-30804-000 | 1 | 1 | 1 |
| GUARD, FAN | 026-25528-700 | 1 | 1 | 1 |
| RING, INLET | 032-00101-700 | 1 | 1 | 1 |
| CHANNEL, CONDENSER ROOF | 063-93734-000 | 1 | 1 | 1 |

Code W - 460-3-60

Code X - 575-3-60

| | | | | |
|------------------------------|---------------|---|---|---|
| MOTOR, FAN, .50HP, 460V | 024-24110-702 | 1 | - | - |
| FAN, PROP, 22DIA, 3BL, 24DEG | 026-32175-000 | 1 | - | - |
| FAN, PROP, 22DIA, 3BL, 34DEG | 026-32173-000 | - | 1 | 1 |
| HARNES, FAN MOTOR | 025-30804-000 | 1 | - | - |
| CAPACITOR, RUN. 7.5MFD | 024-20045-700 | 1 | - | - |
| GUARD, FAN | 026-25528-700 | 1 | - | - |
| RING, INLET | 032-00101-700 | 1 | - | - |
| CHANNEL, CONDENSER ROOF | 063-93734-000 | 1 | - | - |

HEAT SECTION

Gas Heat

N05 - 50MBH Heat Capacity - 2 Tube

Aluminized Steel Heat Exchanger

| | | 208/230-1-60 | 460-3-60 |
|-------------------------------|----------------------|---------------------|-----------------|
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE, HEAT EXCHANGER | 073-13498-000 | 2 | 2 |
| BAFFLE, AIR, 4 TUBE | 063-93668-003 | 1 | 1 |
| BOTTOM, FLUE BOX | 373-02085-001 | 1 | 1 |
| BRACKET, BURNER | 073-05908-000 | 1 | 1 |
| BRACKET, HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET, LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET, MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER, INSHOT | 029-21121-000 | 2 | 2 |
| CONTROL, SPARK | 025-29012-004 | 1 | 1 |
| CONTROL, TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT, EXCHANGER, 2 TUBE | 373-12894-702 | 1 | 1 |
| HOOD, RAIN FLUE | 363-39686-700 | 1 | 1 |
| HOOD, FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER, SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD, GAS | 029-20078-000 | 1 | 1 |
| MOTOR, VENTER, 1/3HP, 208/230 | 024-24115-018 | 1 | - |
| MOTOR, VENTER, 1/3HP, 460V | 024-24115-019 | - | 1 |
| ORIFICE, GAS BURNER, #42 | 029-20423-042 | 2 | 2 |
| ORIFICE, GAS BURNER, BLANK | 029-20423-000 | 3 | 3 |
| ORIFICE, GAS, PILOT, #63 | 029-20422-063 | 1 | 1 |

| | | | |
|---|----------------------|---------------------|-----------------|
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,1.719 DIA. | 063-90038-029 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT | 073-05377-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT | 073-05376-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-701 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |
| S05 - Stainless Steel Heat Exchanger | | | |
| | | 208/230-1-60 | 460-3-60 |
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE,AIR,4 TUBE | 063-93668-003 | 1 | 1 |
| BOTTOM,FLUE BOX | 373-02085-002 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 2 | 2 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT,EXCHANGER,2 TUBE,SS | 373-12894-006 | 1 | 1 |
| HOOD,RAIN FLUE,SS | 026-38657-000 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,VENTER,1/3HP,208/230 | 024-24115-018 | 1 | - |
| MOTOR,VENTER,1/3HP,460V | 024-24115-019 | - | 1 |
| ORIFICE,GAS BURNER,#42 | 029-20423-042 | 2 | 2 |
| ORIFICE,GAS BURNER,BLANK | 029-20423-000 | 3 | 3 |
| ORIFICE,GAS,PILOT,#63 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,1.719 DIA. | 026-39254-000 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT,SS | 026-39252-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT,SS | 026-39251-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-701 | 1 | 1 |

| | | | |
|---|----------------------|---------------------|-----------------|
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |
| N07 - 75MBH Heat Capacity - 3 Tube | | | |
| Aluminized Steel Heat Exchanger | | | |
| | | 208/230-1-60 | 460-3-60 |
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE,HEAT EXCHANGER | 073-13498-000 | 3 | 3 |
| BAFFLE,AIR,3 TUBE | 063-93668-002 | 1 | 1 |
| BOTTOM,FLUE BOX | 373-02085-001 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 3 | 3 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT,EXCHANGER,3 TUBE | 373-12894-703 | 1 | 1 |
| HOOD,RAIN FLUE | 363-39686-700 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,VENTER,1/3HP,208/230 | 024-24115-018 | 1 | - |
| MOTOR,VENTER,1/3HP,460V | 024-24115-019 | - | 1 |
| ORIFICE,GAS BURNER,#42 | 029-20423-042 | 3 | 3 |
| ORIFICE,GAS BURNER,BLANK | 029-20423-000 | 2 | 2 |
| ORIFICE,GAS,PILOT,#63 | 029-20422-063 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,1.906 DIA. | 063-90038-028 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT | 073-05377-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT | 073-05376-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-702 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |
| S07 - Stainless Steel Heat Exchanger | | | |
| | | 208/230-1-60 | 460-3-60 |
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE,AIR,3 TUBE | 063-93668-002 | 1 | 1 |

| | | | |
|----------------------------|----------------------|---|---|
| BOTTOM,FLUE BOX | 373-02085-002 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 2 | 2 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT,EXCHANGER,3 TUBE,SS | 373-12894-007 | 1 | 1 |
| HOOD,RAIN FLUE,SS | 026-38657-000 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,VENTER,1/3HP,208/230 | 024-24115-018 | 1 | - |
| MOTOR,VENTER,1/3HP,460V | 024-24115-019 | - | 1 |
| ORIFICE,GAS BURNER,#42 | 029-20423-042 | 3 | 3 |
| ORIFICE,GAS BURNER,BLANK | 029-20423-000 | 2 | 2 |
| ORIFICE,GAS,PILOT,#63 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,1.906 DIA. | 026-39255-000 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT,SS | 026-39252-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT,SS | 026-39251-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-702 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |

N11 - 100MBH Heat Capacity - 4 Tube

Aluminized Steel Heat Exchanger

| | |
|---------------------|-----------------|
| 208/230-1-60 | 460-3-60 |
| 208/230-3-60 | 575-3-60 |
| 208/230-1-60 | 460-3-60 |
| 208/230-3-60 | 575-3-60 |

| | | | |
|------------------------|----------------------|---|---|
| BAFFLE,HEAT EXCHANGER | 073-13498-000 | 4 | 4 |
| BAFFLE,AIR,4 TUBE | 063-93668-001 | 1 | 1 |
| BOTTOM,FLUE BOX | 373-02085-001 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |

| | | | |
|----------------------------|---------------|---|---|
| BURNER,INSHOT | 029-21121-000 | 4 | 4 |
| CONTROL,SPARK | 025-29012-704 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT,EXCHANGER,4 TUBE | 373-12894-004 | 1 | 1 |
| HOOD,RAIN FLUE | 363-39686-700 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,VENTER,1/3HP,208/230 | 024-24115-018 | 1 | - |
| MOTOR,VENTER,1/3HP,460V | 024-24115-019 | - | 1 |
| ORIFICE,GAS BURNER,#42 | 029-20423-042 | 4 | 4 |
| ORIFICE,GAS BURNER,BLANK | 029-20423-000 | 1 | 1 |
| ORIFICE,GAS,PILOT,#56 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,2.125 DIA. | 063-90038-023 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT | 073-05377-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT | 073-05376-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-701 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |

S11 - Stainless Steel Heat Exchanger

| | | 208/230-1-60 | 460-3-60 |
|---------------------------|----------------------|---------------------|-----------------|
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE,AIR,4 TUBE | 063-93668-001 | 1 | 1 |
| BOTTOM,FLUE BOX | 373-02085-002 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 4 | 4 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT EXCHANGER,4 TUBE, SS | 373-12894-008 | 1 | 1 |
| HOOD,RAIN FLUE,SS | 026-38657-000 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,.03HP,208/230 | 024-24115-018 | 1 | 0 |
| MOTOR,.03HP,460V | 024-24115-019 | 0 | 1 |
| ORIFICE,GAS,BURNER,#42 | 029-20423-042 | 4 | 4 |

| | | | |
|--|----------------------|---------------------|-----------------|
| ORIFICE,GAS,BURNER,BLANK | 029-20423-000 | 1 | 1 |
| ORIFICE,GAS,PILOT,#56 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,2.125DIA | 026-39256-000 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT,SS | 026-39252-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT,SS | 026-39251-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT,145/225 | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-701 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,BLOWER,4DIA,.250BORE | 026-32623-700 | 1 | 1 |
| N13 - 125MBH Heat Capacity - 5 Tube | | | |
| Aluminized Steel Heat Exchanger | | | |
| | | 208/230-1-60 | 460-3-60 |
| | | 208/230-3-60 | 575-3-60 |
| BAFFLE, HEAT EXCHANGER | 073-13498-000 | 5 | 5 |
| BOTTOM,FLUE BOX | 373-02085-001 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 5 | 5 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| HEAT EXCHANGER,5 TUBE | 373-12894-705 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HOOD,RAIN,FLUE | 363-39686-700 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,VENTER,.03HP,208/230 | 024-24115-018 | 1 | 0 |
| MOTOR,VENTER,.03HP,460V | 024-24115-019 | 0 | 1 |
| ORIFICE,GAS,BURNER,#42 | 029-20423-042 | 5 | 5 |
| ORIFICE,GAS,PILOT,#56 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE, 5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,SHOOT THRU 5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,ORIFICE 2.250 DIA | 063-90038-022 | 1 | 1 |
| PLATE,VENT | 073-05377-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT | 073-05376-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SPACER,VENT MOTOR 1/4 X | 063-92626-000 | 4 | 4 |

| | | | |
|---|----------------------|---------------------|-----------------|
| SWITCH,LIMIT 145/225 60TX | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER 4/5 TUBE | 073-12892-701 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,VENTER,BLOWER | 026-32623-700 | 1 | 1 |
| S13 - Stainless Steel Heat Exchanger | | | |
| | | 208/230-1-60 | 460-3-60 |
| | | 208/230-3-60 | 575-3-60 |
| BOTTOM,FLUE BOX | 373-02085-002 | 1 | 1 |
| BRACKET,BURNER | 073-05908-000 | 1 | 1 |
| BRACKET,HEAT EXCHANGER | 073-20260-000 | 2 | 2 |
| BRACKET,LIMIT SWITCH | 073-18432-000 | 1 | 1 |
| BRACKET,MANIFOLD | 063-93548-000 | 1 | 1 |
| BURNER,INSHOT | 029-21121-000 | 5 | 5 |
| CONTROL,SPARK | 025-29012-004 | 1 | 1 |
| CONTROL,TEMPERATURE | 025-32655-000 | 1 | 1 |
| HEAT EXCHANGER,5 TUBE, SS | 373-12894-009 | 1 | 1 |
| HOOD,RAIN FLUE,SS | 026-38657-000 | 1 | 1 |
| HOOD,FURNACE PANEL | 073-21358-000 | 1 | 1 |
| IGNITER,SPARK | 025-30372-000 | 1 | 1 |
| MANIFOLD,GAS | 029-20078-000 | 1 | 1 |
| MOTOR,.03HP,208/230 | 024-24115-018 | 1 | 0 |
| MOTOR,.03HP,460V | 024-24115-019 | 0 | 1 |
| ORIFICE,GAS,BURNER,#42 | 029-20423-042 | 5 | 5 |
| ORIFICE,GAS,PILOT,#56 | 029-20422-056 | 1 | 1 |
| PLATE,BALANCE,5 BURNER | 073-12880-005 | 1 | 1 |
| PLATE,ORIFICE,2.125DIA | 026-39256-000 | 1 | 1 |
| PLATE,SHOOT THRU,5 TUBE | 073-13687-005 | 1 | 1 |
| PLATE,VENT,SS | 026-39252-000 | 1 | 1 |
| SCREEN,1.000X2.000 | 026-31402-000 | 1 | 1 |
| SCROLL,VENT,SS | 026-39251-000 | 1 | 1 |
| SENSOR,FLAME | 025-30802-000 | 1 | 1 |
| SWITCH,LIMIT,145/225 | 025-26392-011 | 1 | 1 |
| SWITCH,LIMIT,SPDT | 025-31830-000 | 1 | 1 |
| TUBE,CARRYOVER,4/5 TUBE | 073-12892-701 | 1 | 1 |
| VALVE,GAS | 025-30105-700 | 1 | 1 |
| WHEEL,BLOWER,4DIA,.250BORE | 026-32623-700 | 1 | 1 |
| ELECTRIC HEAT | | | |
| 208/230-1-60 | | | |
| E05 - 5KW | | | |
| | | 3 Ton | 4 Ton |
| | | 5 Ton | |
| HEATER,ELEC,5.3KW,240V,3ELEM | 025-26319-004 | 1 | 1 |
| | | 1 | 1 |

| | | | | |
|------------------------|---------------|---|---|---|
| RELAY,HEAT SEQUENCER | 024-19082-029 | 1 | 1 | 1 |
| SWITCH,LIMIT | 025-22273-002 | 1 | 1 | 1 |
| FUSE,DUAL,250V,50A | 025-26336-000 | 2 | 2 | 2 |
| FUSE,DUAL,250V,30A | 025-04649-000 | 1 | 1 | 1 |
| FUSEHOLDER,#19,20,250V | 025-26333-000 | 1 | 1 | 1 |

E07 - 7KW

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,7.5KW,240V,3ELEM | 025-26319-002 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-030 | 1 | 1 | 1 |
| SWITCH,LIMIT | 025-22273-002 | 2 | 2 | 2 |
| FUSE,DUAL,250V,40A | 025-26337-000 | 2 | 2 | 2 |
| FUSE,DUAL,250V,50A | 025-26336-000 | 2 | 2 | 2 |
| FUSEHOLDER,#20,250V,30/60A | 025-26340-000 | 1 | 1 | 1 |

E10 - 10KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,10.6KW,240V,3ELEM | 025-26319-003 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |
| FUSE,DUAL,250V 60A | 025-13292-000 | 2 | 2 | 2 |
| FUSE,DUAL,250V 50A, .40X | 025-26336-000 | 2 | 2 | 2 |
| FUSEHOLD,#20,250V,30/60A,4P | 025-26340-000 | 1 | 1 | 1 |

E15 - 15KW

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,15.9KW,240 | 025-26318-001 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-030 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-032 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |
| FUSE,DUAL,250V 30A, 9X16X2 | 025-04649-000 | 2 | 2 | 2 |
| FUSE,DUAL,250V 60A, | 025-13292-000 | 2 | 2 | 2 |
| FUSE,DUAL,250V 50A, .40X | 025-26336-000 | 2 | 2 | 2 |
| FUSEHOLDER,#19,20,20,250V | 025-26341-000 | 1 | 1 | 1 |

E20 - 20KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,21.2KW,240 | 025-26318-002 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-030 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-033 | 2 | 2 | 2 |
| SWITCH,LIMIT,COMB | 025-22273-001 | 5 | 5 | 5 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 1 | 1 | 1 |
| FUSE,DUAL,250V 60A | 025-13292-000 | 4 | 4 | 4 |
| FUSE,DUAL,250V 50A, .40X | 025-26336-000 | 2 | 2 | 2 |
| FUSEHOLDER,#20,250V, 60A,6P | 025-26343-000 | 1 | 1 | 1 |

E30 - 30KW

3 Ton 4 Ton 5 Ton

| | | | | |
|-----------------------------|---------------|---|---|---|
| HEATER,ELEC,29.6KW,240 | 025-26318-003 | - | - | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-030 | - | - | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-033 | - | - | 2 |
| SWITCH,LIMIT,COMB | 025-22273-001 | - | - | 6 |
| FUSE,DUAL,250V 60A | 025-13292-000 | - | - | 8 |
| FUSEHOLDER,#20,250V, 60A,4P | 025-26355-000 | - | - | 2 |

208/230-3-60

E05 - 5KW

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,5.3KW,240V,3ELEM | 025-26319-001 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E07 - 7KW

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,7.5KW,240V,3ELEM | 025-26319-005 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E10 - 10KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,10.6KW,240V,3ELEM | 025-26319-003 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-001 | 3 | 3 | 3 |
| FUSE,DUAL,250V,45A, | 025-08436-000 | 3 | 3 | 3 |
| FUSE,DUAL,250V,35A, | 025-15491-000 | 3 | 3 | 3 |
| FUSEHOLDER,#20,250V,60A | 025-19971-000 | 1 | 1 | 1 |

E20 - 20KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,21.2KW,240 | 025-26318-002 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-034 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-001 | 6 | 6 | 6 |
| FUSE,DUAL,250V 35A | 025-15491-000 | 6 | 6 | 6 |
| FUSE,DUAL,250V,45A | 025-08436-000 | 3 | 3 | 3 |
| FUSEHOLDER,#20,250V, 60A,6P | 025-26343-000 | 1 | 1 | 1 |
| FUSEHOLDER,#20,250V, 60A,3P | 025-26344-000 | 1 | 1 | 1 |

E30 - 30KW

| | | 3 Ton | 4 Ton | 5 Ton |
|------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,29.6KW,240 | 025-26318-003 | - | - | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | - | - | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-034 | - | - | 1 |
| SWITCH,LIMIT,COMB | 025-22273-001 | - | - | 3 |

| | | | | |
|-----------------------------|---------------|---|---|---|
| SWITCH,LIMIT,COMB | 025-22273-003 | - | - | 3 |
| FUSE,DUAL,250V 45A | 025-08436-000 | - | - | 9 |
| FUSEHOLDER,#20,250V, 60A,6P | 025-26343-000 | - | - | 1 |
| FUSEHOLDER,#20,250V, 60A,3P | 025-26344-000 | - | - | 1 |

460-3-60

E07 - 7KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC, 6.8KW,480V,6ELEM | 025-26318-010 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E10 - 10KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,10.0KW,480V,6ELEM | 025-26318-005 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E15 - 15KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,13.6KW,480V.6ELEM | 025-26318-008 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E20 - 20KW

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,19.5KW,480 | 025-26318-007 | 1 | 1 | 1 |
| CONTACTOR,ELEC, | 024-24100-000 | 1 | 1 | 1 |
| CONTACTOR,ELEC, | 024-24101-700 | 2 | 2 | 2 |
| RELAY,CONT 24V,50/60HZSPST | 024-24103-700 | 1 | 1 | 1 |
| CONTROL,TEMP | 025-26339-702 | 1 | 1 | 1 |

E30 - 30KW

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,28.8KW,480 | 025-26318-009 | - | - | 1 |
| CONTACTOR,ELEC, | 024-24100-000 | - | - | 1 |
| CONTACTOR,ELEC, | 024-24101-000 | - | - | 2 |
| RELAY,CONT 24V,50/60HZSPST | 024-24103-000 | - | - | 1 |
| CONTROL,TEMP | 025-26339-001 | - | - | 1 |

575-3-60

E10 - 10KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,10.6KW,600V,6ELEM | 025-26318-004 | 1 | 1 | 1 |

| | | | | |
|----------------------|---------------|---|---|---|
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E15 - 15KW

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,10.0KW,480V,6ELEM | 025-26318-005 | 1 | 1 | 1 |
| RELAY,HEAT SEQUENCER | 024-19082-031 | 1 | 1 | 1 |
| SWITCH,LIMIT,COMB | 025-22273-002 | 3 | 3 | 3 |

E20 - 20KW

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,21.2KW,600 | 025-26318-006 | 1 | 1 | 1 |
| CONTACTOR,ELEC, | 024-24100-700 | 1 | 1 | 1 |
| CONTACTOR,ELEC, | 024-24101-700 | 2 | 2 | 2 |
| RELAY,CONT 24V,50/60HZSPST | 024-24103-700 | 1 | 1 | 1 |
| CONTROL,TEMP | 025-26339-002 | 1 | 1 | 1 |

E30 - 30KW

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------------------|---------------|-------|-------|-------|
| HEATER,ELEC,30.4KW,600 | 025-26318-011 | - | - | 1 |
| CONTACTOR,ELEC, | 024-24100-700 | - | - | 1 |
| CONTACTOR,ELEC, | 024-24101-700 | - | - | 2 |
| RELAY,CONT 24V,50/60HZSPST | 024-24103-700 | - | - | 1 |
| CONTROL,TEMP | 025-26339-001 | - | - | 1 |

DISCONNECT

No Disconnect Option

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------------|---------------|-------|-------|-------|
| COVER,CONTROL BOX | 373-02023-000 | 1 | 1 | 1 |

**Disconnect Option
208/230-1-60**

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| SWITCH,DISCONNECT,150A,600V | 024-24493-200 | 1 | 1 | 1 |
| BRACKET,SWITCH MOUNT | 073-16465-000 | 1 | 1 | 1 |
| COVER,CONTROL BOX | 373-16466-000 | 1 | 1 | 1 |

**Disconnect Option
208/230-3-60, 460-3-60, 575-3-60**

| | | 3 Ton | 4 Ton | 5 Ton |
|-----------------------------|----------------------|-------|-------|-------|
| SWITCH,DISCONNECT,150A,600V | 024-27548-000 | 1 | 1 | 1 |
| BRACKET,SWITCH MOUNT | 073-16465-000 | 1 | 1 | 1 |
| COVER,CONTROL BOX | 373-16466-000 | 1 | 1 | 1 |

**CONVENIENCE OUTLET
No Convenience Outlet
Direct Drive**

3 Ton 4 Ton 5 Ton

| | | | | |
|--|----------------------|-------|-------|-------|
| PANEL,CORNER | 373-26214-001 | 1 | 1 | 1 |
| Belt Drive | | 3 Ton | 4 Ton | 5 Ton |
| PANEL,CORNER | 373-12429-003 | 1 | 1 | 1 |
| Non Powered Convenience Outlet | | | | |
| Direct Drive | | 3 Ton | 4 Ton | 5 Ton |
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| PANEL,CORNER,DIRECT DRIVE, | 373-26214-002 | 1 | 1 | 1 |
| Belt Drive | | 3 Ton | 4 Ton | 5 Ton |
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BELT DRIVE | 373-12429-003 | 1 | 1 | 1 |
| Powered Convenience Outlet | | | | |
| Direct Drive | | | | |
| 208/230 VOLT (1 & 3 Phase) | | 3 Ton | 4 Ton | 5 Ton |
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,208/230-120 | 025-32672-240 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,STD CABINET | 373-26214-002 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,TOOLLESS | 373-26214-004 | 1 | 1 | 1 |
| 460 VOLT | | 3 Ton | 4 Ton | 5 Ton |
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,3KVA,240/480 | 025-32762-000 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,STD CABINET | 373-26214-002 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,TOOLLESS | 373-26214-004 | 1 | 1 | 1 |
| 575 VOLT | | 3 Ton | 4 Ton | 5 Ton |
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,3KVA,600 | 025-30383-000 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |

| | | | | |
|-----------------------------------|---------------|---|---|---|
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,STD CABINET | 373-26214-002 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,DD,TOOLLESS | 373-26114-004 | 1 | 1 | 1 |

Belt Drive

208/230 VOLT (1 & 3 Phase)

3 Ton 4 Ton 5 Ton

| | | | | |
|-----------------------------------|---------------|---|---|---|
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,208/230-120V | 025-32672-240 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,STD CABINET | 373-12429-003 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,TOOLLESS | 373-12429-004 | 1 | 1 | 1 |

460 VOLT

3 Ton 4 Ton 5 Ton

| | | | | |
|-----------------------------------|---------------|---|---|---|
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,3KVA,240/480 | 025-32762-000 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,STD CABINET | 373-12429-003 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,TOOLLESS | 373-12429-004 | 1 | 1 | 1 |

575 VOLT

3 Ton 4 Ton 5 Ton

| | | | | |
|-----------------------------------|---------------|---|---|---|
| OUTLET,CONVENIENCE | 025-31987-000 | 1 | 1 | 1 |
| SWITCH,TOGGLE,30A,600V | 024-26065-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,20A,250V | 024-27517-000 | 1 | 1 | 1 |
| TRANSFORMER,3KVA,600PRI | 025-30383-000 | 1 | 1 | 1 |
| FUSE,600V,30A | 025-32733-001 | 2 | 2 | 2 |
| FUSEHOLDER,#1,600V,30A,1P | 025-17407-000 | 2 | 2 | 2 |
| COVER,SWITCH | 025-31977-000 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,STD CABINET | 373-12429-003 | 1 | 1 | 1 |
| PANEL,CORNER,FRONT,BD,TOOLLESS | 373-12429-004 | 1 | 1 | 1 |

SMOKE DETECTOR - SUPPLY AIR

No Smoke Detector

3 Ton 4 Ton 5 Ton

| | | | | |
|--------------|----------------------|---|---|---|
| HARNES, WIRE | 025-35366-009 | 1 | 1 | 1 |
|--------------|----------------------|---|---|---|

With Smoke Detector

| | | | | |
|----------------|----------------------|---|---|---|
| SMOKE DETECTOR | 029-22291-000 | 1 | 1 | 1 |
|----------------|----------------------|---|---|---|

SMOKE DETECTOR - RETURN AIR

No Smoke Detector

| | | 3 Ton | 4 Ton | 5 Ton |
|--------------|----------------------|-------|-------|-------|
| HARNES, WIRE | 025-35366-009 | 1 | 1 | 1 |

With Smoke Detector

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------|----------------------|-------|-------|-------|
| SMOKE DETECTOR | 029-22291-000 | 1 | 1 | 1 |

ECONOMIZER

No Economizer

| | | 3 Ton | 4 Ton | 5 Ton |
|----------------|---------------|-------|-------|-------|
| HARNES, JUMPER | 363-89845-604 | 1 | 1 | 1 |

**With Economizer
Single Enthalpy**

| | | 3 Ton | 4 Ton | 5 Ton |
|---------------------------|---------------|-------|-------|-------|
| PLATE, DIVIDER ECONOMIZER | 073-26258-000 | 1 | 1 | 1 |
| FILTER, AIR, CLEANABLE | 026-25514-000 | 2 | 2 | 2 |
| DAMPER, AIR | 373-21440-000 | 1 | 1 | 1 |
| ACTUATOR | 025-38231-000 | 1 | 1 | 1 |
| CONTROL, LOGIC | 031-01965-000 | 1 | 1 | 1 |
| BALL JOINT | 029-08786-000 | 1 | 1 | 1 |
| COVER, TOP FILTER | 063-89630-700 | 1 | 1 | 1 |
| ANGLE, BOTTOM, FRESH AIR | 063-89632-700 | 1 | 1 | 1 |
| CONTROL, ENTHALPY | 031-00863-000 | 1 | 1 | 1 |
| BLADE, DAMPER | 073-21445-000 | 1 | 1 | 1 |
| SEAL, DAMPER BLADE | 029-18443-000 | 2 | 2 | 2 |
| SEAL, DAMPER BLADE | 029-18442-000 | 1 | 1 | 1 |
| CONNECTOR, 1/4" | 029-18438-000 | 1 | 1 | 1 |
| BRACKET, DAMPER | 029-18440-000 | 3 | 3 | 3 |
| BRACKET, DAMPER | 029-22132-000 | 8 | 8 | 8 |
| PIVOT, BRASS W/SET SCREW | 029-18439-000 | 7 | 7 | 7 |
| BRACKET, DAMPER BLADE | 729-20068-000 | 2 | 2 | 2 |
| BRACKET, DAMPER BLADE | 029-20091-000 | 1 | 1 | 1 |

MOTORIZED DAMPER

| | | 3 Ton | 4 Ton | 5 Ton |
|-------------|---------------|-------|-------|-------|
| DAMPER, AIR | 373-21440-000 | 1 | 1 | 1 |
| ACTUATOR | 025-26351-700 | 1 | 1 | 1 |
| BALL JOINT | 029-08786-700 | 1 | 1 | 1 |

| | | | | |
|-----------------------------|---------------|---|---|---|
| PLATE,DIVIDER | 072-21441-000 | 1 | 1 | 1 |
| PANEL,SIDE,R.H. | 063-89623-700 | 1 | 1 | 1 |
| PANEL,SIDE,L.H. | 063-89624-700 | 1 | 1 | 1 |
| COVER, TOP, FILTER | 063-89630-700 | 1 | 1 | 1 |
| COVER, TOP, FRESH AIR HOOD | 063-89632-700 | 1 | 1 | 1 |
| ANGLE,BOTTOM,FRESH AIR HOOD | 063-89632-700 | 1 | 1 | 1 |
| FILTER,AIR,CLEANABLE | 026-25514-000 | 2 | 2 | 2 |

BAS READY COMPONENTS

| | | 230V | 460V | 575V |
|--------------------------------|---------------|------|------|------|
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230-24 | 025-25973-000 | 1 | - | - |
| TRANSFORMER,.075KVA,460 | 025-25974-000 | - | 1 | - |
| TRANSFORMER,75KVA | 025-27732-000 | - | - | - |
| TRANSFORMER,575V/24V/75A | 025-27729-000 | - | - | 1 |
| TERMINAL BLOCK,2P,250V,20A | 025-30887-000 | 1 | 1 | 1 |

BAS CPC

| | | 230V | 460V | 575V |
|--------------------------------|----------------------|------|------|------|
| CONTROL,CPC | 031-01940-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER 3.2A 250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF 50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA 208/230-24 | 025-25973-700 | 1 | - | - |
| TRANSFORMER,.075 KVA 460PRI-24 | 025-25974-700 | - | 1 | - |
| TRANSFORMER,575V/24V 75A | 025-27729-700 | - | - | 1 |
| SWITCH,PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY SS DC CONTROL | 024-32008-000 | 1 | 1 | 1 |
| SENSOR,TEMP,CPC | 031-01945-000 | 2 | 2 | 2 |
| BRACKET,SENSOR | 063-87678-000 | 1 | 1 | - |

BAS NOVAR

| | | 230V | 460V | 575V |
|--------------------------------|----------------------|------|------|------|
| CONTROL,NOVAR | 031-01939-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER 3.2A 250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF 50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA 208/230-24 | 025-25973-700 | 1 | - | - |
| TRANSFORMER,.075 KVA 460PRI-24 | 025-25974-700 | - | 1 | - |
| TRANSFORMER,575V/24V 75A | 025-27729-700 | - | - | 1 |
| SWITCH, PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY SS DC CONTROL | 024-32008-000 | 1 | 1 | 1 |
| SENSOR,TEMPERATURE,NOVAR | 031-01944-000 | 2 | 2 | 2 |

**BAS JOHNSON CONTROL
NO ECONOMIZER**

| | | 230V | 460V | 575V |
|-----------------------------|----------------------|------|------|------|
| CONTROL | 031-01937-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF,50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-000 | 1 | - | 1 |
| TRANSFORMER,.075KVA,460 | 025-25974-000 | - | 1 | - |
| SWITCH,PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY,SS,AC CONTROL | 024-32027-000 | 1 | 1 | 1 |
| SENSOR,TEMPERATURE,JCI | 031-01946-000 | 1 | 1 | 1 |

WITH ECONOMIZER

| | | 230V | 460V | 575V |
|--------------------------------|----------------------|------|------|------|
| CONTROL,JOHNSON UNIT | 031-01937-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER 3.2A 250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF 50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA 208/230-24 | 025-25973-700 | 1 | - | - |
| TRANSFORMER,.075 KVA 460PRI-24 | 025-25974-700 | - | 1 | - |
| TRANSFORMER, 575V/24V 75A | 025-27729-700 | - | - | 1 |
| SWITCH, PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY,SS AC CONTROL | 024-32027-000 | 1 | 1 | 1 |
| SENSOR,TEMPERATURE,JCI | 031-01946-000 | 2 | 2 | 2 |
| SENSOR | 031-01120-000 | 1 | 1 | 1 |
| BRACKET,SENSOR | 063-87678-000 | 1 | 1 | 1 |

**BAS HONEYWELL CONTROL
NO ECONOMIZER**

| | | 230V | 460V | 575V |
|-----------------------------|----------------------|------|------|------|
| CONTROL,HONEYWELL | 031-01938-000 | 1 | 1 | 1 |
| CONTROL,ISOLATION RELAY | 031-01941-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER,3.2A,250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF,50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA,208/230 | 025-25973-700 | 1 | - | 1 |
| TRANSFORMER,.075KVA,460 | 025-25974-700 | - | 1 | - |
| TRANSFORMER,575KVA,24V,75A | 025-27729-000 | - | - | 1 |
| SWITCH,PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY,SS,DC CONTROL | 024-32008-000 | 1 | 1 | 1 |
| SENSOR,TEMPERATURE,20K OHM | 031-01943-000 | 2 | 2 | 2 |

WITH ECONOMIZER

230V 460V 575V

| | | | | |
|--------------------------------|---------------|---|---|---|
| CONTROL,HONEYWELL | 031-01938-000 | 1 | 1 | 1 |
| CONTROL,ISOLATION RELAY | 031-01941-000 | 1 | 1 | 1 |
| CONTROL,ENTHALPY | 031-00863-000 | 1 | 1 | 1 |
| CIRCUIT BREAKER 3.2A 250V | 024-31976-000 | 1 | 1 | 1 |
| CAPACITOR,100UF 50WVDC | 031-01956-000 | 1 | 1 | 1 |
| TRANSFORMER,.075KVA 208/230-24 | 025-25973-700 | 1 | - | - |
| TRANSFORMER,.075 KVA 460PRI-24 | 025-25974-700 | - | 1 | - |
| TRANSFORMER, 575V/24V 75A | 025-27729-700 | - | - | 1 |
| SWITCH,PRESSURE TAP | 023-16881-000 | 1 | 1 | 1 |
| SWITCH,PRESSURE DIFF | 024-32007-000 | 2 | 2 | 2 |
| RELAY,SS DC CONTROL | 024-32008-000 | 1 | 1 | 1 |
| SENSOR,TEMP,20K OHM | 331-01943-000 | 2 | 2 | 2 |
| RESISTOR,500 OHM | 031-01942-000 | 1 | 1 | 1 |