



Source 1
Replacement Parts

Supersedes : 035-19412-001-A-0303

BB 3 thru 5 Ton
Single Package Heat Pump
Standard-Efficiency
035-19412-001-B-0603

Note: This is a non-comprehensive parts list intended for stocking purposes for first production (style A) units based on current production. It is not intended to replace the comprehensive list with subsequent changes.

COMMON PARTS

BRACKET,FILTER,TOP	029-18445-000		1
BRACKET,FILTER,MIDDLE	029-18446-000		1
BRACKET,FILTER,BOTTOM	029-18447-000		1
RAIL,BASE	063-87534-001		2
RAIL,END	063-87544-001		1
RAIL,END	063-89741-000		1
PANEL,COMPRESSOR ACCESS	063-87559-000		1
POST,CORNER,FRONT	063-87617-000		1
POST,CORNER,REAR	063-87618-000		1
PANEL,BAFFLE,FILTER,LH	073-21209-000		1
BRACKET, TOP	073-21697-000		1
BRACKET,BASE	073-21698-000		1
COVER, DUCT	363-87667-000		3
COVER, BASE DUCT	363-89742-000		1
COVER,BASE DUCT	373-03111-000		1
PANEL,BLOWER SECTION	373-03098-100		1
ROOF, EVAPORATOR	373-03102-102		1
PAN,CONDENSATE,STANDARD	363-87677-000		1
PAN,CONDENSATE	063-94795-001		1
ELBOW,90 DEGREE,PVC	023-13649-000		1
BUSHING,CONDUIT	025-26385-000		1
PAN,CONDENSATE,DOWN DRAIN	363-87677-001		1
PAN,CONDENSATE	063-94795-002		1
ADAPTER,PVC,3/4SLP	023-16807-000		1
BUSHING,CONDUIT	025-26385-000		1
PANEL,HEAT SECTION,COOLING ONLY	373-03096-000		1

CABINET OPTIONS

Standard Cabinet

Cooling/Elec Heat

PANEL,FILTER SECTION	363-87539-000		1
POST,CABINET	073-26149-001		1
PANEL,DUCT	373-03097-000		1
PANEL,ACCESS,ELECTRIC HEAT	373-03088-001		1

Gas Heat

PANEL,FILTER SECTION	363-87539-000		1
POST,CABINET	073-26149-001		1

Source 1 Products

035-19412-002-B-0603
Supersedes: 035-19412-001-A-0303

New Replacement Parts shown in bold face at the first printing of the parts list

**Toolless Cabinet
Cooling/Elec Heat**

PANEL,FILTER ACCESS	373-20676-000		1
POST,CABINET	073-26149-002		1
PANEL,DUCT	373-14781-206		1
PANEL,ACCESS,ELECTRIC HEAT	373-03088-002		1
PLATE,LATCH	073-01920-000		2
PLATE,LATCH	073-01931-000		7
KNOB,TEE STUD	029-22127-000		11

Gas Heat

PANEL,FILTER ACCESS	373-20676-000		1
POST,CABINET	073-26149-002		1
PANEL,DUCT	373-14781-206		1
PANEL,ACCESS,GAS HEAT	073-05379-002		1
PLATE,LATCH	073-01920-000		2
PLATE,LATCH	073-01931-000		7
KNOB,TEE STUD	029-22127-000		11

PLATE,LATCH	073-01931-000		7
KNOB,TEE STUD	029-22127-000		11

FILTER OPTIONS

FILTER,AIR,1X14X25	026-10019-000		1
FILTER,AIR,1X15X20	036-34786-000		2
FILTER,AIR,2X14X25,PLEATED	026-38038-000		1
FILTER,AIR,2X15X20,PLEATED	026-38039-000		2

COMPRESSORS

Code F - 208/230-1-60

		3 Ton	4 Ton	5 Ton
COMPRESSOR,CR38K6-PFV	015-02422-001	1	-	-
COMPRESSOR,H25A46QCBCA	015-02568-001	-	1	-
COMPRESSOR,ZR61K3-PFV	015-02645-004	-	-	1
CAPACITOR,RUN,40.0/ 7.5MFD,440V	024-21679-000	1	-	-
CAPACITOR,RUN,50.0/5.0MFD,440V	024-25896-000	-	-	-
CAPACITOR,RUN,80.0/ 7.5MFD	024-25912-000	-	-	1
START ASSIST DEVICE	024-25095-001	-	1	-
GROMMET	028-11969-000	4	4	-
GROMMET	028-12357-000	4	4	-
GROMMET,RUBBER	028-13344-000	-	-	4
SPRING MTG. COMPRESSOR	029-20421-000	4	4	-

Code T - 208/230-3-60

		3 Ton	4 Ton	5 Ton
COMPRESSOR,CR38K6-TF5	015-02423-001	1	-	-
COMPRESSOR,H25A46QDBLA	015-02569-001	-	1	-
COMPRESSOR,ZR61K3-TF5	015-02646-004	-	-	1
GROMMET	028-11969-000	4	4	-
GROMMET,	028-12357-000	4	4	-
GROMMET,RUBBER	028-13344-000	-	-	4
SPRING MTG. COMPRESSOR	029-20421-000	4		-

Code W - 460-3-60

		3 Ton	4 Ton	5 Ton
COMPRESSOR,CR38K6-TFD	015-02424-001	1	-	-
COMPRESSOR,H25A46QDBEA	015-02570-001	-	1	-
COMPRESSOR,ZR61K3-TFD	015-02647-004	-	-	1
GROMMET	028-11969-000	4	4	-
GROMMET	028-12357-000	4	4	-
GROMMET,RUBBER	028-13344-000	-	-	4
SPRING MTG. COMPRESSOR	029-20421-000	4	4	-

Code X - 575-3-60

		3 Ton	4 Ton	5 Ton
COMPRESSOR,CR38K6-TFE	015-03155-001	1	-	-
COMPRESSOR,H25A46QDBFA	015-02571-001	-	1	-
COMPRESSOR,ZR61K3-TFE	015-02648-004	-	-	1
GROMMET	028-11969-000	4	4	-
GROMMET	028-12357-000	4	4	-
GROMMET,RUBBER	028-13344-000	-	-	4
SPRING MTG. COMPRESSOR	029-20421-000	4	4	-

ELECTRICAL BOX

BELT DRIVE

Code F - 208/230-1-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR	024-27531-000	1	1	-
CONTACTOR,ELEC,20AMP,1P	024-25964-000	1	1	1
CONTACTOR,ELEC,40 AMP	024-25837-000	-	-	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V,20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075KVA 208/230-24 R:D	025-25973-000	1	1	1

Code T - 208/230-3-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP, 2 P	024-25965-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V,20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-000	1	1	1

Code W - 460-3-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP, 2 P	024-25965-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V,20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075 KVA 460PRI-24	025-25974-000	1	1	1

Code X - 575-3-60

		3 Ton	4 Ton	5 Ton
BOARD, CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP, 2 P	024-25965-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK,2P,300V,20A	025-23083-000	1	1	1

TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075 KVA 460PRI-24	025-25974-000	1	1	1
TRANSFORMER,750 VA,240/480 PRI	025-32758-000	1	1	1

Cooling Only - DIRECT DRIVE

Code F - 208/230-1-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR	024-27531-000	1	1	-
CONTACTOR,ELEC,20AMP,1P	024-25964-000	1	1	1
CONTACTOR,ELEC,40 AMP	024-25837-000	-	-	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V,20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-000	1	1	1

Code T - 208/230-3-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP, 1 P	024-25964-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V, 20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSF .075KVA 208/230-24	025-25973-000	1	1	1

Code W - 460-3-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP, 1 P	024-25964-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1

CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V, 20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSF .075 KVA 460PRI-24	025-25974-000	1	1	1

Code X - 575-3-60

		3 Ton	4 Ton	5 Ton
BOARD,CIRCUIT	331-01934-004	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTACTOR,ELEC,20AMP,1P	024-25964-000	1	1	1
CONTACTOR,ELEC,30 AMP	024-25955-000	1	1	1
CONTROL,DEFROST	031-01971-000	1	1	1
CONTROL,TEMP SPST 45F	025-35355-000	1	1	1
CONTROL,TEMP SWITCH SPST	025-38585-000	1	1	1
LUG,ELECTRICAL	025-21798-000	1	1	1
RELAY,CONT 24V50/60HZDPDT	024-23972-000	1	1	1
RELAY,CONT 24V50/60HZSPDT	024-24116-000	1	1	1
TERMINAL BLOCK, 2P,300V, 20A	025-23083-000	1	1	1
TERMINAL,GROUNDING	025-29006-000	1	1	1
TRANSFORMER,.075 KVA 460PRI-24	025-25974-000	1	1	1
TRANSFORMER,750 VA,240/480 PRI	025-32758-000	1	1	1

CONDENSER COIL

		3 Ton	4 Ton	5 Ton
COIL,CONDENSER,FORMED	373-05958-100	1	-	-
COIL,CONDENSER,TECHNICOAT	373-05958-150	1	-	-
COIL,CONDENSER,FORMED	373-05958-101	-	1	-
COIL,CONDENSER,TECHNICOAT	373-05958-151	-	1	-
COIL,CONDENSER,FORMED	373-07683-100	-	-	1
COIL,CONDENSER,TECHNICOAT	373-07683-152	-	-	1
VALVE,DISTRIBUTOR,3 TUBE,# 68	022-06844-022	1	-	-
VALVE,DISTRIBUTOR,3 TUBE,# 76	022-06844-049	-	1	-
VALVE,DISTRIBUTOR,5 TUBE,# 82	022-06844-052	-	-	1
HEADER,SUCTION	373-05958-001	1	-	-
HEADER,SUCTION	373-05958-050	-	1	-
HEADER,CONDENSER	373-07683-050	-	-	1

EVAPORATOR COIL
Belt Drive

3 Ton 4 Ton 5 Ton

COIL,EVAPORATOR,BELT DRIVE	373-26201-003	1	-	-
COIL,EVAPORATOR, TECHNICOAT	373-26201-031	1	-	-
COIL,EVAPORATOR,BELT DRIVE	373-26201-006	-	1	-
COIL,EVAPORATOR, TECHNICOAT	373-26201-034	-	1	-
COIL,EVAPORATOR,BELT DRIVE	373-26201-009	-	-	1
COIL,EVAPORATOR, TECHNICOAT	373-26201-037	-	-	1
VALVE,DISTRIBUTOR, 3 TUBE,# 80	022-06844-069	1	-	-
VALVE,DISTRIBUTOR,3 TUBE,# 84	022-06844-066	-	1	-
VALVE,DISTROBITPR,6 TUBE,# 98	022-06844-071	-	-	1
HEADER,ID COIL,3 TON	363-89826-000	1	-	-
HEADER,ID COIL,4 TON	373-07633-050	-	1	-
HEADER,ID COIL,5 TON	373-07684-050	-	-	1

Direct Drive Drive

		3 Ton	4 Ton	5 Ton
COIL,EVAPORATOR	373-26201-001	1	-	-
COIL,EVAPORATOR, TECHNICOAT	373-26201-029	1	-	-
COIL,EVAPORATOR,	373-26201-004	-	1	-
COIL,EVAPORATOR, TECHNICOAT	373-26201-032	-	1	-
COIL,EVAPORATOR,	373-26201-007	-	-	1
COIL,EVAPORATOR, TECHNICOAT	373-26201-035	-	-	1
VALVE,DISTR,3 TON	022-06844-069	1	-	-
VALVE,DISTR,4 TON	022-06844-050	-	1	-
VALVE,DISTR,5 TON	022-06844-051	-	-	1
HEADER,ID COIL,3 TON	363-89826-000	1	-	-
HEADER,ID COIL,4 TON	373-07633-051	-	1	-
HEADER,ID COIL,5 TON	373-07684-050	-	-	1

PIPING

Belt Drive

		3 Ton	4 Ton	5 Ton
ACCUMULATOR	026-25573-001	1	-	-
ACCUMULATOR	026-25573-002	-	1	-
ACCUMULATOR	026-25573-003	-	-	1
SWITCH,LOW PRESSURE	025-30249-000	1	1	1
SWITCH,HIGH PRESSURE	025-35356-000	1	1	1
CONTROL,TEMPERATURE	325-26354-001	1	1	1
CONTROL,TEMPERATURE	025-23282-000	1	1	1
CONTROL,TEMPERATURE	325-27727-029	1	1	1
FILTER,SOLID	026-25512-000	1	1	1
CORE,V PORT,SCHRAEDER	022-02475-000	2	2	2
CAP,SEAL,1/4 FLARE	023-10745-000	2	2	2
STEM,VALVE,1/4 O.D.	022-08017-000	1	1	1

Direct Drive

3 Ton 4 Ton 5 Ton

ACCUMULATOR	026-25573-001	1	-	-
ACCUMULATOR	026-25573-002	-	1	
ACCUMULATOR	026-25573-003	-	-	1
SWITCH,LOW PRESSURE	025-30249-000	1	1	1
SWITCH,HIGH PRESSURE	025-35356-000	1	1	1
CONTROL,TEMPERATURE	325-26354-001	1	1	1
CONTROL,TEMPERATURE	025-23282-000	1	1	1
CONTROL,TEMPERATURE	325-27727-029	1	1	1
FILTER,SOLID	026-25512-000	1	1	1
CORE,V PORT,SCHRAEDER	022-02475-000	2	2	2
CAP,SEAL,1/4 FLARE	023-10745-000	2	2	2
STEM,VALVE,1/4 O.D.	022-08017-000	1	1	1

BLOWER,EVAPORATOR

Belt Drive

Motors - Including Sheaves and Belts

Code F - 208/230-1-60

		3 Ton	4 Ton	5 Ton
MOTOR,1.5 HP 115/230 1PH	024-25868-000	1	1	1
BLOWER,BELT DRIVE,12 X 10	026-25539-001	1	1	1
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1
CAP,RUN,25.0/ MFD,370V	024-23181-000	1	1	1
BELT,V, A35,36.3	028-09572-000	-	-	1
BELT,V, A36,37.3	028-09573-000	1	1	-
SHEAVE,VARIABLE,1GRV, .625BORE	028-12361-000	1	1	1
SHEAVE,FIXED,1GRV,1.000BORE	028-12363-000	-	-	1
SHEAVE,FIXED,1GRV,1.000BORE	028-12383-000	1	1	-

Code T - 208/230-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,BLOWER,1.5HP,208/460	024-19623-018	1	1	1
BLOWER,BELT DRIVE,12 X 10	026-25539-001	1	1	1
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1
BELT,V, A35,36.3	028-09572-000	-	-	1
BELT,V,A36, 37.3	028-09573-000	1	1	-
SHEAVE,FIXED,1GRV,1.000BORE	028-12363-000	-	-	1
SHEAVE,FIXED,1GRV,1.000BORE	028-12383-000	1	1	-
SHEAVE,VARIABLE,1GRV, .878BORE	028-12385-000	1	1	1

Code W - 460-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,BLOWER,1.5HP,208/460	024-19623-018	1	1	1
BLOWER,BELT DRIVE,12 X 10	026-25539-001	1	1	1
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1
BELT,V,A35,36.3	028-09572-000	-	-	1
BELT,V,A36,37.3	028-09573-000	1	1	-
SHEAVE,FXD,1GRV,1.000BORE	028-12363-000	-	-	1

SHEAVE,FXD,1GRV,1.000BORE	028-12383-000	1	1	-
SHEAVE,VAR,1GRV, .878BORE	028-12385-000	1	1	1
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1

Code X - 575-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,BLOWER,1.5HP,575V	024-19623-007	1	1	1
BLOWER,BELT DRIVE,12 X 10	026-25539-001	1	1	1
SHAFT,BLOWER,12"/15"WHEEL	001-07115-000	1	1	1
BELT,V A35 36.3	028-09572-000	-	-	1
BELT,V A36 37.3	028-09573-000	1	1	-
SHEAVE,FXD,1GRV,1.000BORE	028-12363-000	-	-	1
SHEAVE,FXD,1GRV,1.000BORE	028-12383-000	1	1	-
SHEAVE,VAR,1GRV, .878BORE	028-12385-000	1	1	1

Common Parts - Belt Drive

		3 Ton	4 Ton	5 Ton
KEY,STL,1/4 SQ X 4.000 LG	001-07110-002	1	1	1
KEY,STL,1/4 SQ X 2.000 LG	001-07110-005	1	1	1
BEARING,BALL PILLOW BLOCK	029-20424-000	2	2	2
BRACKET,BEARING SUPPORT	073-12442-000	2	2	2
BRACKET,MOTOR PIVOT	073-12444-000	1	1	1
BRACKET,MOTOR ADJUSTMENT	073-15128-000	1	1	1

Direct Drive

Codes F & T - 208/230-1-60 & 208/230-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,.5HP 230V 3 SPEED	024-24106-001	1	-	-
MOTOR, .75HP 230V 3 SPEED	024-21670-001	-	1	-
MOTOR,1HP 230V 3 SPEED	024-21672-001	-	-	1
CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-000	1	-	-
CAPACITOR,RUN,12.5/ MFD,370V	024-25899-000	-	1	-
CAPACITOR,RUN,15.0/ MFD,370V	024-25900-000	-	-	1

Code W - 460-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,.5HP 460V 3 SPEED	024-24107-001	1	-	-
MOTOR,3/4 HP 460V	024-21671-002	-	1	-
MOTOR,1HP 460V 3 SPEED	024-25000-002	-	-	1
CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-000	1	-	-
CAPACITOR,RUN,12.5/ MFD,370V	024-25899-000	-	1	-
CAPACITOR,RUN,25.0/ MFD,370V	024-23181-000	-	-	1

Code X - 575-3-60

		3 Ton	4 Ton	5 Ton
MOTOR,.5HP 460V 3 SPEED	024-24107-001	1	-	-
MOTOR,3/4 HP 460V	024-21671-002	-	1	-
MOTOR,1HP 460V 3 SPEED	024-25000-002	-	-	1

CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-000	1	-	-
CAPACITOR,RUN,12.5/ MFD,370V	024-25899-000	-	1	-
CAPACITOR,RUN,25.0/ MFD,370V	024-23181-000	-	-	1

Common Parts - Direct Drive

		3 Ton	4 Ton	5 Ton
BLOWER,DIRECT DRIVE 12 X	026-25539-000	1	1	1
HANGER,MOTOR	026-32681-000	1	1	1

CONDENSER FAN

Code F - 208/230-1-60

MOTOR,.33HP,SINGLE SPEED	024-24117-701	1	-	-
MOTOR,FAN,.50HP,208/230V	024-24110-701	-	1	1
FAN,PROP,24DIA,2BL,23DEG	026-32175-000	1	-	-
FAN,PROP,22DIA,3BL,34DEG	026-32173-000	-	1	-
FAN,PROP,24DIA,3BL,25DEG	026-25515-700	-	-	1
CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-700	-	-	1
HARNESS,CONDENSER FAN	025-30892-000	1	-	1
HARNESS,FAN MOTOR	025-30804-000	-	1	-
GUARD,FAN	026-25528-700	1	1	1
RING,INLET	063-89756-000	-	-	1
ORIFICE,FAN	032-00101-000	1	1	-
CHANNEL,CONDENSER ROOF	063-93734-000	1	1	1

Code T - 208/230-3-60

MOTOR,.33HP,SINGLE SPEED	024-24117-701	1	-	-
MOTOR,FAN,.50HP,208/230V	024-24110-701	-	1	1
FAN,PROP,24DIA,2BL,23DEG	026-32175-000	1	-	-
FAN,PROP,22DIA,3BL,34DEG	026-32173-000	-	1	-
FAN,PROP,24DIA,3BL,25DEG	026-25511-000	-	-	1
CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-700	1	-	1
HARNESS,CONDENSER FAN	025-30892-000	1	-	1
HARNESS,FAN MOTOR	025-30804-000	-	1	-
GUARD,FAN	026-25528-700	1	1	1
RING,INLET,22"	032-00101-000	1	1	-
CHANNEL,CONDENSER ROOF	063-93734-000	1	1	1

Code W - 460-3-60

Code X - 575-3-60

MOTOR,.33HP,SINGLE SPEED	024-24117-702	1	-	-
MOTOR,.33HP,SINGLE SPEED	024-24110-702	-	1	1
FAN,PROP,22DIA,3BL,34DEG	026-32175-000	1	-	-
FAN,PROP,22DIA,3BL,34DEG	026-32173-000		1	
FAN,PROP,24DIA,3BL,25DEG	026-25511-700	-	-	1
HARNESS,CONDENSER FAN	025-30892-000	1	-	-
HARNESS,CONDENSER FAN	025-30804-000	-	1	1

CAPACITOR,RUN, 7.5/ MFD,370V	024-20045-000	1	1	1
GUARD,FAN	026-25528-000	1	1	1
ORIFICE,FAN	063-89756-000	-	-	1
RING,INLET	032-00101-000	1	1	-
CHANNEL,CONDENSER ROOF	063-93734-000	1	1	1

ELECTRIC HEAT

Code F - 208/230-1-60

5KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,5.3KW,240V,3ELEM	025-26319-004	1	1	1
RELAY,HEAT SEQUENCER	024-19082-029	1	1	1
SWITCH,LIMIT	025-22273-002	1	1	1
FUSE,DUAL,250V,50A	025-26336-000	2	2	2
FUSE,DUAL250V,30A	025-04649-000	1	1	1
FUSEHOLDER,#19,20,250V	025-26333-000	1	1	1

7KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,7.5KW,240V,3ELEM	025-26319-002	1	1	1
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1
SWITCH,LIMIT	025-22273-002	2	2	2
FUSE,DUAL,250V,40A	025-26337-000	2	2	2
FUSE,DUAL,250V,50A	025-26336-000	2	2	2
FUSEHOLDER,#20,250V,30/60A	025-26340-000	1	1	1

10KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,10.6KW240V,3ELEM	025-26318-003	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
FUSE,DUAL,250V 60A	025-13292-000	2	2	2
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2
FUSEHOLD,#20,250V,30/60A,4P	025-26340-000	1	1	1

15KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,15.9KW,240	025-26318-001	1	1	1
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1
RELAY,HEAT SEQUENCER	024-19082-032	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2
FUSE,DUAL,250V 30A, 9X16X2	025-04649-000	2	2	2
FUSE,DUAL,250V 60A,	025-13292-000	2	2	2

FUSEHOLDER,#19,20,20,250V	025-26341-000	1	1	1
---------------------------	---------------	---	---	---

20KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,21.2KW,240	025-26318-002	1	1	1
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1
RELAY,HEAT SEQUENCER	024-19082-033	2	2	2
SWITCH,LIMIT,COMB	025-22273-001	5	5	5
SWITCH,LIMIT,COMB	025-22273-002	1	1	1
FUSE,DUAL,250V 60A	025-13292-000	4	4	4
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	1	1	1

30KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,29.6KW,240	025-26318-003	-	-	1
RELAY,HEAT SEQUENCER	024-19082-030	-	-	1
RELAY,HEAT SEQUENCER	024-19082-033	-	-	2
SWITCH,LIMIT,COMB	025-22273-001	-	-	6
FUSE,DUAL,250V 60A	025-13292-000	-	-	8
FUSEHOLDER,#20,250V, 60A,4P	025-26355-000	-	-	2

Code T - 208/230-3-60

5KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,5.3KW,240V,3ELEM	025-26319-001	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3

7KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,7.5KW,240V,3ELEM	025-26319-005	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3

10KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,10.6KW,240V,3ELEM	025-26319-003	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-001	3	3	3
FUSE,DUAL,250V,45A,	025-08436-000	3	3	3
FUSE,DUAL,250V,35A,	025-15491-000	3	3	3
FUSEHOLDER,#20,250V,60A	025-19971-000	1	1	1

15KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,15.9KW,240	025-26318-001	1	1	1
RELAY,HEAT SEQUENCER	024-19082-030	1	1	1
RELAY,HEAT SEQUENCER	024-19082-032	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
FUSE,DUAL,250V 30A, 9X16X2	025-04649-000	2	2	2
FUSE,DUAL,250V 60A,	025-13292-000	2	2	2
FUSE,DUAL,250V 50A, .40X	025-26336-000	2	2	2
FUSEHOLDER,#19,20,20,250V	025-26341-000	1	1	1

20KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,21.2KW,240	025-26318-002	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
RELAY,HEAT SEQUENCER	024-19082-034	1	1	1
SWITCH,LIMIT,COMB	025-22273-001	6	6	6
FUSE,DUAL,250V 35A	025-15491-000	6	6	6
FUSE,DUAL,250V,45A	025-08436-000	3	3	3
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	1	1	1
FUSEHOLDER,#20,250V, 60A,3P	025-26344-000	1	1	1

30KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,29.6KW,240	025-26318-003	-	-	1
RELAY,HEAT SEQUENCER	024-19082-031	-	-	1
RELAY,HEAT SEQUENCER	024-19082-034	-	-	1
SWITCH,LIMIT,COMB	025-22273-001	-	-	3
SWITCH,LIMIT,COMB	025-22273-003	-	-	3
FUSE,DUAL,250V 45A	025-08436-000	-	-	9
FUSEHOLDER,#20,250V, 60A,6P	025-26343-000	-	-	1
FUSEHOLDER,#20,250V, 60A,3P	025-26344-000	-	-	1

Code W - 460-3-60

7KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC, 6.8KW480V,6ELEM	025-26318-010	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3

10KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,10.0KW480V,6ELEM	025-26318-005	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3

15KW

		3 Ton	4 Ton	5 Ton
HEATER,ELEC,13.6KW480V,6ELEM	025-26318-008	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
20KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,19.5KW,480	025-26318-007	1	1	1
CONTACTOR,ELEC,	024-24100-000	1	1	1
CONTACTOR,ELEC,	024-24101-000	2	2	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	1	1	1
CONTROL,TEMP	025-26339-002	1	1	1
30KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,28.8KW,480	025-26318-009	-	-	1
CONTACTOR,ELEC,	024-24100-000	-	-	1
CONTACTOR,ELEC,	024-24101-000	-	-	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	-	-	1
CONTROL,TEMP	025-26339-001	-	-	1
Code X - 575-3-60				
10KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,10.6KW600V,6ELEM	025-26318-004	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
15KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,10.0KW480V,6ELEM	025-26318-005	1	1	1
RELAY,HEAT SEQUENCER	024-19082-031	1	1	1
SWITCH,LIMIT,COMB	025-22273-002	3	3	3
20KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,21.2KW,600	025-26318-006	1	1	1
CONTACTOR,ELEC,	024-24100-000	1	1	1
CONTACTOR,ELEC,	024-24101-000	2	2	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	1	1	1
CONTROL,TEMP	025-26339-002	1	1	1
30KW				
		3 Ton	4 Ton	5 Ton
HEATER,ELEC,30.4KW,600	025-26318-011	-	-	1
CONTACTOR,ELEC,	024-24100-000	-	-	1

CONTACTOR,ELEC,	024-24101-000	-	-	2
RELAY,CONT 24V50/60HZSPST	024-24103-000	-	-	1
CONTROL,TEMP	025-26339-001	-	-	1

DISCONNECT

No Disconnect Option

3 Ton 4 Ton 5 Ton

COVER,CONTROL BOX	373-02023-000	1	1	1
-------------------	---------------	---	---	---

Disconnect Option

Code F - 208/230-1-60

3 Ton 4 Ton 5 Ton

SWITCH,DISCONNNECT,150A,600V	024-24493-200	1	1	1
BRACKET,SWITCH MOUNT	073-16465-000	1	1	1
COVER,CONTROL BOX	373-16466-000	1	1	1

Disconnect Option

208/230-3-60, 460-3-60, 575-3-60

3 Ton 4 Ton 5 Ton

SWITCH,DISCONNNECT,150A,600V	024-27548-000	1	1	1
COVER,CONTROL BOX	373-16466-000	1	1	1
BRACKET,SWITCH MOUNT	073-16465-000	1	1	1

CONVENIENCE OUTLET

No Convenience Outlet

Belt Drive

3 Ton 4 Ton 5 Ton

PANEL,CORNER	373-12429-003	1	1	1
--------------	---------------	---	---	---

None Powered Convenience Outlet, Standard Cabinet

Direct Drive

3 Ton 4 Ton 5 Ton

OUTLET,CONVENIENCE	025-31987-000	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1
PANEL,CORNER,DIRECT DRIVE	373-26214-002	1	1	1

Belt Drive

3 Ton 4 Ton 5 Ton

OUTLET,CONVENIENCE	025-31987-000	1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000	1	1	1
PANEL,CORNER,FRONT,BELT DRIVE	373-12429-003	1	1	1

Powered Convenience Outlet

Direct Drive

208/230 VOLT (1 & 3 Phase)

3 Ton 4 Ton 5 Ton

OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1

TRANSFORMER,208/230-120	025-32672-240		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002		1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26214-004		1	1	1
460 VOLT			3 Ton	4 Ton	5 Ton
OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1
TRANSFORMER,3KVA,240/480	025-32762-000		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002		1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26214-004		1	1	1
575 VOLT			3 Ton	4 Ton	5 Ton
OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1
TRANSFORMER,3KVA,600	025-30383-000		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,DD,STD CABINET	373-26214-002		1	1	1
PANEL,CORNER,FRONT,DD,TOOLLESS	373-26114-004		1	1	1
Belt Drive					
208/230 VOLT (1 & 3 Phase)			3 Ton	4 Ton	5 Ton
OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1
TRANSFORMER,208/230-120V	025-32672-240		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003		1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004		1	1	1
460 VOLT			3 Ton	4 Ton	5 Ton
OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1
TRANSFORMER,3KVA,240/480	025-32762-000		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2

FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003		1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004		1	1	1

575 VOLT

3 Ton 4 Ton 5 Ton

OUTLET,CONVENIENCE	025-31987-000		1	1	1
SWITCH,TOGGLE,30A,600V	024-26065-000		1	1	1
CIRCUIT BREAKER,20A,250V	024-27517-000		1	1	1
TRANSFORMER,3KVA,600PRI	025-30383-000		1	1	1
FUSE,600V,30A	025-32733-001		2	2	2
FUSEHOLDER,#1,600V,30A,1P	025-17407-000		2	2	2
COVER,SWITCH	025-31977-000		1	1	1
PANEL,CORNER,FRONT,BD,STD CABINET	373-12429-003		1	1	1
PANEL,CORNER,FRONT,BD,TOOLLESS	373-12429-004		1	1	1

SMOKE DETECTOR - SUPPLY AIR

No Smoke Detector

3 Ton 4 Ton 5 Ton

HARNESS,WIRE	025-35366-009	1	1	1
--------------	---------------	---	---	---

With Smoke Detector

SMOKE DETECTOR	029-22291-000	1	1	1
----------------	---------------	---	---	---

SMOKE DETECTOR - RETURN AIR

No Smoke Detector

3 Ton 4 Ton 5 Ton

HARNESS,WIRE	025-35366-009	1	1	1
--------------	---------------	---	---	---

With Smoke Detector

SMOKE DETECTOR	029-22291-000	1	1	1
----------------	---------------	---	---	---

DIRTY FILTER SWITCH

3 Ton 4 Ton 5 Ton

SWITCH,PRESSURE	024-32007-000	1	1	1
-----------------	---------------	---	---	---

PHASE MONITOR

3 Ton 4 Ton 5 Ton

PHASE MONITOR,0-600V	031-01922-000	1	1	1
----------------------	---------------	---	---	---

GUARD,COIL

		3 Ton	4 Ton	5 Ton
GUARD,COIL	026-25570-017	1	1	1

ECONOMIZER

Single Enthalpy

		3 Ton	4 Ton	5 Ton
PLATE,DIVIDER ECONOMIZER	073-26258-000	1	1	1
FILTER,AIR,CLEANABLE	026-25514-000	2	2	2
DAMPER,AIR	373-21440-000	1	1	1
ACTUATOR	025-38231-000	1	1	1
CONTROL,LOGIC	031-01965-000	1	1	1
BALL JOINT	029-08786-000	1	1	1
COVER, TOP FILTER	063-89630-700	1	1	1
ANGLE,BOTTOM,FRESH AIR	063-89632-700	1	1	1
CONTROL,ENTHALPY	031-00863-000	1	1	1
BLADE,DAMPER	073-21445-000	1	1	1
SEAL,DAMPER BLADE	029-18443-000	2	2	2
SEAL,DAMPER BLADE	029-18442-000	1	1	1
CONNECTOR,1/4"	029-18438-000	1	1	1
BRACKET,DAMPER	029-18440-000	3	3	3
BRACKET,DAMPER	029-22132-000	8	8	8
PIVOT,BRASS W/SET SCREW	029-18439-000	7	7	7
BRACKET,DAMPER BLADE	729-20068-000	2	2	2
BRACKET,DAMPER BLADE	029-20091-000	1	1	1

MOTORIZED DAMPER

		3 Ton	4 Ton	5 Ton
DAMPER,AIR	373-21440-000	1	1	1
ACTUATOR	025-26351-700	1	1	1
BALL JOINT	029-08786-700	1	1	1
PLATE,DIVIDER	072-21441-000	1	1	1
PANEL,SIDE,R.H.	063-89623-700	1	1	1
PANEL,SIDE,L.H.	063-89624-700	1	1	1
COVER, TOP, FILTER	063-89630-700	1	1	1
COVER, TOP, FRESH AIR HOOD	063-89632-700	1	1	1
ANGLE,BOTTOM,FRESH AIR HOOD	063-89632-700	1	1	1
FILTER,AIR,CLEANABLE	026-25514-000	2	2	2

BAS READY COMPONENTS

		230V	460V	575V
CIRCUIT BREAKER,3.2A,250V	024-31976-000	1	1	1
TRANSFORMER, .075KVA,208/230-24	025-25973-700	1	-	-
TRANSFORMER, .075KVA,460	025-25974-700	-	1	-
TRANSFORMER,75KVA	025-27732-700	-	-	-
TRANSFORMER,575V/24V/75A	025-27729-700	-	-	1
TERMINAL BLOCK,2P,250V,20A	025-30887-000	1	1	1

BAS CPC

		230V	460V	575V
CONTROL,CPC	031-01940-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SWITCH, PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY,SS,DC CONTROL	024-32008-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER,075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER,575V/24V 75A	025-27729-700	-	-	1
SENSOR,TEMPERATURE,CPC	031-01945-000	2	2	2
SENSOR,TEMP,CPC	031-01945-000	2	2	-
BRACKET,SENSOR	063-87678-000	1	1	-

BAS NOVAR

		230V	460V	575V
CONTROL,NOVAR	031-01939-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SWITCH,PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY,SS DC CONTROL	024-32008-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER,.075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER,575V/24V 75A	025-27729-700	-	-	1
SENSOR,TEMP,NOVAR	031-01944-000	2	2	2
SENSOR,TEMP,NOVAR	031-01944-000	2	2	2

**BAS JOHNSON CONTROL
NO ECONOMIZER**

		230V	460V	575V
CONTROL,JOHNSON UNIT	031-01937-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CAPACITOR,100UF 50WVDC	031-01956-000	1	1	1
SWITCH,PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY,SS AC CONTROL	024-32027-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER,.075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER,575V/24V 75A	025-27729-700	-	-	1
SENSOR,TEMP,JCI	031-01946-000	2	2	2
SENSOR,TEMP,JCI	031-10946-000	2	2	2
BRACKET,SENSOR	063-87678-000	1	1	1

**BAS HONEYWELL CONTROL
NO ECONOMIZER**

		230V	460V	575V
CONTROL,HONEYWELL	031-01938-000	1	1	1
CIRCUIT BREAKER 3.2A 250V	024-31976-000	1	1	1
CONTROL,ISOLATION RELAY	031-01941-000	1	1	1
CAPACITOR,100UF 50VVDC	031-01956-000	1	1	1
SWITCH,PRESSURE TAP	023-16881-000	1	1	1
SWITCH,PRESSURE DIFF	024-32007-000	2	2	2
RELAY,SS DC CONTROL	024-32008-000	1	1	1
TRANSFORMER,.075KVA 208/230-24	025-25973-700	1	-	-
TRANSFORMER,.075 KVA 460PRI-24	025-25974-700	-	1	-
TRANSFORMER,575V/24V 75A	025-27729-700	-	-	1
SENSOR,TEMP 20K OHM	031-01943-000	2	2	2
SENSOR,TEMP,20K OHM	031-10943-000	2	2	2